

**CNA 300/200 TEST MEASUREMENT
SOFTWARE OPERATING MANUAL**

**Transat Corporation
31000 Bainbridge Road
Solon, Ohio 44139**

July 21, 1997

**Copyright © 1997
All Rights Reserved**

| | |
|---|-----------|
| 1 INTRODUCTION | 1 |
| 1.1 Hardware and Software Requirements | 1 |
| 1.2 Technical Specifications of the CNA 300 | 1 |
| 1.3 Technical Specifications of the CNA 200 | 1 |
| 1.4 CNA Software | 1 |
| 1.4.1 HARDWARE.CNA File | 2 |
| 2 CONVENTIONS | 3 |
| 2.1 Choosing Menu Items | 3 |
| 2.2 Function Keys | 3 |
| 2.3 Entering/Modifying Parameters | 3 |
| 3 GETTING STARTED | 5 |
| 4 A QUICK TUTORIAL ON USING THE CNA | 7 |
| 4.1 Preparing To Measure a Crystal | 7 |
| 4.2 Selecting the Tests to Run | 9 |
| 4.3 Starting the Test | 10 |
| 5 PERFORMING A TEST | 13 |
| 5.1 Specify a Test Setup | 13 |
| 5.2 Entering the Lot Description | 14 |
| 5.3 Modifying the Current Test Setup | 15 |
| 5.3.1 Basic Test Window | 17 |
| 5.3.2 Fs Test Window (Series Frequency) | 18 |
| 5.3.3 R Test Window (Resistance) | 19 |
| 5.3.4 L1 Test Window (Motional Inductance) | 19 |
| 5.3.5 C1 Test Window (Motional Capacitance) | 20 |
| 5.3.6 C0 Test Window (Static Capacitance) | 20 |
| 5.3.7 Q Test Window (Quality Factor) | 21 |
| 5.3.8 SP Test Window (Spurious Search) | 21 |
| 5.3.9 DL Test Window (Drive Level) | 22 |
| 5.3.10 FL1 Test Window (Load Frequency) | 22 |
| 5.3.11 FL2 and FL3 Test Window (Load Frequency) | 23 |
| 5.3.12 C0/C1 Ratio Test | 23 |
| 5.4 Starting a Test | 24 |
| 6 SETUP TEST | 27 |
| 6.1 Creating and Modifying Setup Tests | 27 |

| | | |
|----------|--|-----------|
| 6.2 | Load Setup Test | 28 |
| 6.3 | Save Setup Test | 29 |
| 6.4 | Create Setup Test | 29 |
| 6.5 | Delete Setup Test | 30 |
| 6.6 | Modifying Measurement Parameters | 30 |
| 6.7 | Modifying Load Capacitance Measurement Parameters | 33 |
| 7 | WORKING WITH DATA FROM PREVIOUS TESTS | 35 |
| 7.1 | Review Test Data from Previous Test Runs | 35 |
| 7.2 | Review Distribution Data | 36 |
| 7.3 | Regenerate Test Reports | 36 |
| 7.4 | Export Data | 36 |
| 7.5 | Delete Old Test Data | 37 |
| 8 | CONFIGURING THE SYSTEM | 39 |
| 8.1 | Calibrating the Instrument | 39 |
| 8.2 | Setting Up How Reports are Printed and/or Saved in Log Files | 41 |
| 8.2.1 | Modifying the Print/Log Setup | 42 |
| 8.2.2 | Viewing Log Files | 43 |
| 8.2.3 | Printing Log Files | 43 |
| 8.2.4 | Deleting Log Files | 44 |
| 8.2.5 | Selecting a Custom Report Script File | 44 |
| 8.2.6 | Selecting an External Report | 45 |
| 8.3 | Quick Measurement Screen | 46 |
| 8.3.1 | Status Line | 47 |
| 8.3.2 | Measurement Menu | 47 |
| 8.3.2.1 | Using the Sweep Control Menu | 48 |
| 8.3.2.2 | Modifying the Current Setup | 49 |
| 8.3.3 | Performing a Sweep Measurement | 51 |
| 8.3.4 | Modifying How a Sweep Measurement is Made | 51 |
| 8.3.5 | Performing File Maintenance | 52 |
| 8.3.6 | Internal Parameters | 54 |
| 8.4 | Modifying Internal Parameters | 54 |
| 8.4.1 | System Parameters Screen | 56 |
| 8.4.2 | Digital I/O Parameters Screen | 58 |
| 8.4.3 | External I/O Parameters Screen | 59 |

| | |
|---|-----------|
| 8.4.4 FFC Card Parameters Screen (CNA 300 Only) | 60 |
| 8.4.5 Calibration File Maintenance Screen | 61 |
| 8.4.6 Parameter File Paths Screen | 62 |
| 8.4.7 Plating Rate Control Setup Parameters Screen (CNA 300 Only) | 63 |
| 8.4.8 Alternative Spurious Search | 65 |
| APPENDIX A MEASUREMENT TYPES | 67 |
| A.1 Frequency (CNA 300 Only) | 67 |
| A.2 Freq & Resist (CNA 300 Only) | 67 |
| A.3 Standard Par (CNA 300 Only) | 68 |
| A.4 Special Par (CNA 300 Only) | 69 |
| A.5 Multi Point (CNA 300 Only) | 70 |
| A.6 Sweep Measurement | 72 |
| A.7 Phase Locked Impedance | 72 |
| A.8 Frequency Set Impedance | 73 |
| A.9 Insert Capacitance | 73 |
| A.10 Spurious Search | 73 |
| A.11 DL Test or DLD Sweep | 73 |
| A.12 Calculate CL | 74 |
| APPENDIX B LOAD CAPACITANCE MEASUREMENTS | 75 |
| B.1 Numerical | 75 |
| B.2 Physical | 75 |
| B.3 EQREACT | 75 |
| B.4 Measure Reference Crystal | 76 |
| APPENDIX C EXPORTING DATABASE DATA | 77 |
| C.1 Exporting Data Using System Menus | 77 |
| C.2 Exporting Data Using Batch Files | 77 |
| C.3 Export Data File Descriptions | 77 |
| APPENDIX D USING R&R REPORT WRITER® TO CUSTOMIZE REPORTS | 83 |
| APPENDIX E CREATING CUSTOM REPORTS USING SCRIPT FILES | 85 |
| APPENDIX F SYSTEM MENUS | 95 |
| APPENDIX G SAMPLE REPORTS | 97 |

1 INTRODUCTION

The CNA (Crystal Network Analyzer) 300 and CNA 200 Test Measurement Systems are designed to quickly and accurately measure crystal devices. With their simple and intuitive operating menus, production tests can be completed quickly. Additional flexibility is provided for Engineering to aid in analyzing crystal characteristics and identifying production problems.

The CNA 300 performs both phase-locked and frequency-locked measurements, while the CNA 200 only performs frequency-locked measurements. In both the CNA 300 and CNA 200, crystal parameters and limit specifications can be saved in Setup files for future use. Test data can be printed and/or exported to industry standard DBF (dBASE) files.

1.1 Hardware and Software Requirements

The system software runs on a 486 computer with a minimum speed of 66 MHz. The system software requires:

- DOS 6.22 or higher, and at least 4 MB of RAM,
- A minimum of a hard disk and a 3 1/2" 1.44 MB floppy drive, and
- A VGA monitor.

1.2 Technical Specifications of the CNA 300

| | |
|------------------|---|
| Frequency Range: | 1 to 256 MHz |
| Ext Reference: | 10 MHz into 50 Ohms at 50 mV (optional) |
| Sensitivity: | |
| Input Channel A: | 3.7 μ V - 240 mV rms 1 to 256 MHz |
| Input Channel B: | 0.9 μ V - 60 mV rms 1 to 256 MHz |
| Output: | 0.05 to 2 V rms, 1 - 256 MHz |
| Power: | 100/120/200/220/240 @ < 50 W |

1.3 Technical Specifications of the CNA 200

| | |
|------------------|---|
| Frequency Range: | 1 to 200 MHz |
| Ext Reference: | 10 MHz into 50 Ohms at 50 mV (optional) |
| Sensitivity: | |
| Input Channel A: | 3.7 μ V - 240 mV rms 1 to 200 MHz |
| Input Channel B: | 0.9 μ V - 60 mV rms 1 to 200 MHz |
| Output: | 0.05 to 2 V rms, 1 - 200 MHz |
| Power: | 100/120/200/220/240 @ < 50 W |

1.4 CNA Software

The software is structured for two main operating modes:

- Production "test," designed for repetitive crystal tests and for use by unskilled operators. The tests can be set up by a skilled operator, for various formats and requirements, including PASS or FAIL limits. After a test is set up, it can be saved, so that the system can automatically be configured to perform the same test at a later time.
- Laboratory "Quick Measurements," designed for a variety of engineering measurements, including impedance measurements of electronic components other than crystal devices.

The software is located in the directory C:\TESTMEAS.

1.4.1 HARDWARE.CNA File

The **HARDWARE.CNA** file contains calibration data from the factory for this particular CNA. Each CNA has a unique **HARDWARE.CNA** file. **DO NOT CHANGE** this file.

If you have multiple CNAs, make sure that the appropriate **HARDWARE.CNA** file is used with each CNA.

2 CONVENTIONS

This chapter provides a guide to help users understand how to navigate the menus and how to modify parameters.

2.1 Choosing Menu Items

Menus contain numbered lists. The items in the list are functions that the software can perform. To cause a menu item to be performed, type its number at the prompt.

2.2 Function Keys

The following table describes the function keys that are always active in the system.

| Press | To |
|-----------|--|
| <F1> | Display help information. Press <ESC> to exit Help. |
| <ALT-F9> | Temporarily shell to the DOS prompt to perform DOS related functions. To return back to the CNA software at the exact place where <ALT-F9> was pressed, type EXIT at the DOS prompt. |
| <ALT-F10> | Shut down the CNA software and return to DOS. |

2.3 Entering/Modifying Parameters

To position the cursor to the desired location on data entry screens, press the <TAB>, <UP-ARROW>, or <DOWN-ARROW> keys repeatedly until the cursor is positioned on the desired field. The currently selected parameter will always be highlighted.

Some parameters are modified by entering the desired value directly, while others display a selection box from which the appropriate value may be selected. A message at the bottom of the screen indicates how to modify the currently selected parameter.

Examples of messages:

Press <SPACE> to select, then <RETURN> to confirm or <ESCAPE> to abort

Pressing <SPACE> displays a list of values that the parameter can be set to. Cursor through the list using either the <SPACE>, <UP-ARROW>, or <DOWN-ARROW> keys. When the desired value is highlighted, press <ENTER>.

Press <SPACE> to toggle value ON (1) or OFF (0)

Pressing <SPACE> causes the highlighted value to toggle between 0 and 1.

Enter the new value, then <ENTER> to confirm or <ESCAPE> to abort

Type in the new value. A data entry box automatically displays when you begin typing. Press <ENTER> when complete.

3 GETTING STARTED

To start, turn power on to the CNA System. After a few minutes, a screen titled "Verify Serial Number" appears. The serial number located on the front of the CNA should be identical to the serial number that appears on the screen. Because each CNA possesses a unique calibration file, unmatched serial numbers will generate incorrect results.




Figure 3.1 Verify Serial Number

After a key is pressed, the Main menu will display.

The test operator only needs to be concerned with the Test option. The other options should only be used by those responsible for configuring or maintaining the system. Except for the View Data option, all other options can be password protected to prevent inadvertent changes to setup parameters.

```

TRANSAT CNA-300 Crystal Measurement System U3.03
< Main System Menu >                                09:47:16
  
```

```

ENTER SELECTION : [ █ ]
1. RUN TEST
2. SETUP TEST
3. VIEW DATA
4. CONFIGURE SYSTEM
  
```

Figure 3.2 Main Menu Screen

The following table describes the menu options available from the Main Menu.

| Press | To select | To |
|-------|------------|---|
| <1> | Run Test | Begin the test/measurement process. Allows the operator to modify parameters and perform measurements on crystals. Selecting this option enters the Test menu. See Chapter 5, "PERFORMING A TEST" for more information. |
| <2> | Setup Test | Allow the operator to create, modify, save, and delete Setup files from the disk. A Setup file contains information defining the test of a specific class of crystals. A Setup file should be created for each class of crystal you will be testing. Selecting this option enters the Setup Model menu. See Chapter 6, "SETUP TEST" for more information. |

| Press | To select | To |
|--------------|------------------|---|
| <3> | View Data | Allow the operator to view Log files from prior tests. Selecting this option enters the View menu. See Chapter 7, "WORKING WITH DATA FROM PREVIOUS TESTS" for more information. |
| <4> | Configure System | Allow the operator to modify system parameters. Selecting this option enters the Configure menu. See Chapter 8, "CONFIGURING THE SYSTEM" for more information. |

4 A QUICK TUTORIAL ON USING THE CNA

This chapter takes you step-by-step through the process of selecting the tests to run and performing the test. See Chapter 5, "PERFORMING A TEST", for a thorough description on how to set up and perform tests and measurements. See Chapter 6, "SETUP TEST", for a complete description on how to create, modify, and delete Setup files.

Generally, before measuring a crystal, do the following:

- Provide some basic test information about the crystal.
- Select which tests to perform.
- Run the test.

4.1 Preparing To Measure a Crystal

In this example, we will be testing the Series Frequency and Resistance of a crystal.

To prepare to measure the crystal device

1. Place the crystal device in the PI Network. Be sure to place each leg of the crystal device on a different contact.
2. From the Main menu, press <1> to choose Run Test.

The Run Test Menu screen displays. The screen is setup to either accept typing in the name of the file or pressing <ENTER> to show the list of files.

In our example, the Run Test Menu file is named SYSFILE. SYSFILE is included with the system software. A later section describes how to create other test setups that can be used here.

```

TRANSAT CNA-300 Crystal Measurement System V3.03          10:14:32
< Run Test Menu >

```

```

Setup To Load : ██████████

```

```

Enter Name, or press ENTER for list

```

Figure 4.1 Test Setup Screen

3. Press <ENTER> to display a list, then press <ENTER> to accept SYSFILE.

The Lot screen displays.

```

TRANSAT CNA-300 Crystal Measurement System U3.11 09:04:16
< Run Test Menu >

```

```

TEST SETUP : SYSFILE

```

```

Lot Name          : LOGFILE

```

Enter a new filename, then <ENTER> to confirm or <ESCAPE> to abort

Figure 4.2 Lot Screen

4. Press <ENTER> to accept the Lot Name of LOGFILE.

If LOGFILE already exists, you will be asked to press <1> to overwrite the existing data. Otherwise, the test will be aborted.

The Current Test Setup screen displays.

```

TRANSAT CNA-300 Crystal Measurement System U3.03 10:23:16
< Run Test Menu >

```

```

CURRENT TEST SETUP : SYSFILE  PATH:

```

Test List

```

DP: 100.000 uW  ESR: 5.0 Ω  Delay: 5 msec  Log: 1  Pwt: 0  Dst: 1
FS = 9.9970000 MHz within 0.000 ppm and 200.000 ppm
R = within 28.0 Ω and 32.0 Ω
SP = search 2 ppm and mark spurs ≥ 3.000 dB

```

| | | | | | | | | |
|-------------|------------|-----------|--------------|---------------|----|----|----|----|
| F1 START | F2 EDIT | F3 ADD | F4 DELETE | F5 DEL ALL | F6 | F7 | F8 | F9 |
|-------------|------------|-----------|--------------|---------------|----|----|----|----|

Figure 4.3 Current Test Setup Screen

4.2 Selecting the Tests to Run

The Setup file selected has a set of tests previously defined. These tests are shown in the Test List. The Test List can be modified per the user's test requirements.

To select the tests to be run

1. Press <F2> EDIT

The Basic Test window displays

```

===== Basic Test =====
Drive Power : 100.000  $\mu$ W   Log Name   : LOGFILE   Logging : 1
ESR         : 20.0  $\Omega$    Serial Name : TRANSAT   Printing : 0
Delay Time  : 5 msec     Serial #    : 1         Distributions : 1
Report      : COMPLETE

Press END to accept changes, ESCAPE to ABORT
  
```

Figure 4.4 Basic Test Window

2. Enter these values in the Basic Test window:

Drive Power: 100 μ W,
 ESR: 20.0 ohms,
 Delay Time: 5 milliseconds.

NOTE Press <ENTER> after typing in a value. Pressing <Tab> or an arrow key causes the old value to display.

3. Press <END> to accept the changes and return to the Current Test Setup screen.

The Test list will now contain the values you entered in the Basic Test window.

4. Use the Up- and Down-Arrow Keys to highlight FS, then press <ENTER>.

The Fs (Series Frequency) Test window displays.

```

===== Fs Test =====
Target Freq(MHz) Lower Upper Units
Fs 9.9982300 -10.000 10.000 ppm

Press END to accept changes, ESCAPE to ABORT
  
```

Figure 4.5 Fs Test Window

5. Enter these values in the Fs Test window:

Target Frequency: 9.9982300 MHz
 Lower: -10.0
 Upper: 10.0
 Units: ppm

6. Press <END> to accept the changes and return to the Current Test Setup screen.

The Test list will now contain the values you entered in the Fs Test window.

7. Use the Up- and Down-Arrow Keys to highlight R, then press <ENTER>.

The R (Resistance) Test window displays.




Figure 4.6 R Test Window

8. Enter these values in the R Test window:

Lower: 1.0 ohms
Upper: 20.0 ohms

9. Press <END> to accept the changes and return to the Current Test Setup screen.

The Test list will now contain the values you entered in the R Test window.

4.3 Starting the Test

You are now ready to start testing. You can perform the test on as many crystals as you want, but please note that the tests you just selected, are not saved. For more information on saving Setup files, see Chapter 6, "SETUP TEST".

To perform the test

1. Press <F1> to choose Start.

The Test screen displays.





Figure 4.7 Test Screen

- Press <SPACE> to perform the measurement.
The crystal device is measured, and the results are placed on the screen.



ESC to EXIT - SPACE to Measure - ANY KEY TO CONTINUE

Figure 4.8 Test Screen After Measurement is Completed

To repeat the test on another crystal using the same test setup

- Remove the crystal device that has been measured from the PI Network, and place a new crystal device in the PI Network.
- Press <SPACE> to measure the crystal.

The new crystal is measured, and the results are placed on the Test screen.

Repeat the above two steps for each crystal device in the lot.

The measurements made on each crystal device are recorded in the Log file, named after the Lot Name, if logging was enabled.

5 PERFORMING A TEST

This chapter describes how to setup and begin testing a group of crystals. The test setup can either be from a setup file (Setup Test) or defined at the start of the test.

The steps necessary for performing a test are as follows:

- Specify a test setup.
- Enter lot description.
- Modify the current test setup (optional).
- Start the test.

NOTE For maximum performance, allow the system to warm up 1 hour after it is powered up before making measurements.

5.1 Specify a Test Setup

To specify a test setup

- From the Main menu, press <1> to select RUN TEST.

The Test Setup screen is displayed similar to the following.

```

TRANSTAT CNA-300 Crystal Measurement System U3.03          10:14:32
< Run Test Menu >

Setup To Load : ██████████

```

Enter Name, or press ENTER for list

Figure 5.1 Test Setup Screen

You can use a pre-defined Setup Test or temporarily modify it for the test.

To select a Setup Test

1. Type in the name of the Setup Test.

To load a Setup Test from a list, press <ENTER>. Use the Up- and Down-Arrow Keys to select from the list of Setup Tests.

2. Press <ENTER>.

5.2 Entering the Lot Description

The system needs to know the following information about the lot:

- A unique Lot Name for compiling test data.

When a Setup Test is selected in the Test Setup screen, the Lot Description screen is displayed.

```

TRANSAT CNA-300 Crystal Measurement System V3.11      09:04:16
< Run Test Menu >
TEST SETUP : SYSPFILE

Lot Name           : LOGFILE

```

Enter a new filename, then <ENTER> to confirm or <ESCAPE> to abort

Figure 5.2 Lot Description Screen

The following table describes the parameters on the Lot Description screen.

| Parameter | Description |
|--|---|
| Lot Name | The name that uniquely identifies the group of parts to be tested. This parameter has a maximum of 8 alpha-numeric characters. This is used as the name of the log file. |
| Measure Reference Crystal | If set to 1, the effective load capacitance is measured based on inserting a reference crystal before starting a test. This is a method for determining the value for Target Cap used in FL1, FL2, and FL3 tests. |
| <p>NOTE This is only displayed if FL1, FL2, or FL3 test is selected AND Load CL Mode is EQREACT. (See Appendix B, "LOAD CAPACITANCE MEASUREMENTS" for more information on the different load capacitance measurements.)</p> | |

5.3 Modifying the Current Test Setup

After entering the information in the Lot Description screen, the Current Test Setup screen is displayed.




Figure 5.3 Current Test Setup Screen

In this screen you will be making a list of the tests you want to perform. The following table describes the options.

| Choose | To |
|--------------|--|
| <F1> Start | Start the test. Select this option after you are done adding, modifying, and/or deleting tests to the list of tests you want to perform. Choosing this option causes the Test screen to display. Tests and measurements are performed from the Test screen. The Test screen is described in Section 5.4. |
| <F2> Edit | Edit an existing test. Use the Up- and Down-Arrow Keys to highlight the desired test. Press <F2>. When a test is selected, its window displays. Each test window is described in Section 5.3. |
| <F3> Add | Add a new test. When selected, a list of the tests not currently in the Test List box displays. Use the Up- and Down-Arrow Keys to highlight the desired test. Press <ENTER> to select the highlighted test. When a test is selected, its window displays. Each test window is described in Section 5.3. |
| <F4> Delete | Delete a test. Use the Up- and Down-Arrow Keys to highlight the desired test. Press <F4>. When a test is selected, a confirmation window displays with the name of the test. |
| <F5> Del All | Delete All tests except the BasicTest. Press <F5>. A confirmation window displays. |

Before measuring a crystal, you must select the tests to be performed. The following table lists the different tests available and the section in which each test is described.

| Test | Description | Section the test is explained |
|------------|--|-------------------------------|
| Basic Test | Setup information about the crystal needed before any tests are performed. | Section 5.3.1 |
| FS | Series Frequency test | Section 5.3.2 |
| R | Series Resistance test | Section 5.3.3 |

| Test | Description | Section the test is explained |
|-------------|---------------------------|--------------------------------------|
| L1 | Motional Inductance test | Section 5.3.4 |
| C1 | Motional Capacitance test | Section 5.3.5 |
| C0 | Static Capacitance test | Section 5.3.6 |
| Q | Quality Factor test | Section 5.3.7 |
| SP | Spur Search test | Section 5.3.8 |
| DL | Drive Level test | Section 5.3.9 |
| FL1 | Load Frequency 1 test | Section 5.3.10 |
| FL2 | Load Frequency 2 test | Section 5.3.11 |
| FL3 | Load Frequency 3 test | Section 5.3.11 |
| C0/C1 | Ratio of C0 to C1 test | Section 5.3.12 |

To edit a test

1. Use the Up- and Down-Arrow Keys to select a test.
2. Press <F2>.
3. Enter the parameters associated with the test chosen. See the following sections for descriptions of each test.
4. Press <END> to accept all parameters.
5. Repeat steps 1 through 4 for each test you want to edit.

To add a test

1. Press <F3>.
2. In the 'SELECT TEST' list box, use the Up- and Down-Arrow Keys to highlight the desired test to add.
3. Press <ENTER>.
4. Enter the parameters associated with the test chosen. See the following sections for descriptions of each test.
5. Press <END> to accept all parameters.
6. Repeat steps 1 through 5 for each test you want to add.

To delete a test

1. Use the Up- and Down-Arrow Keys to select a test.
2. Press <F4>.
3. A confirmation window appears with the name of the test.
4. Repeat steps 1 through 3 for each test you want to delete.

To delete all tests

1. Press <F5>.

2. A confirmation window appears.

The following sections describe each test and the associated parameters.

5.3.1 Basic Test Window

The parameters in this window **MUST** be set before any tests or measurements are performed. (The parameters in either the FS or the FLI Test window must also be set before any tests or measurements are performed.)




Figure 5.4 Basic Test Window

Selecting Basic Test does not perform any tests or measurements. It supplies the system with information common to all tests.

The parameters in the Basic Test Window are described in the following table.

| Parameter | Description |
|-------------------|---|
| Drive Power (uW) | The drive power applied to the crystal device. NOTE This value is also used as the high-drive level setting for the Drive-Level test. |
| ESR (ohms) | The expected series resistance of the crystal. ESR and Drive Power parameters are used to program the output of the CNA. |
| Delay Time (mSec) | Delay Time is the amount of time the system waits at each point while sweeping the part. A typical value to use is 10 ms. Crystals with a larger Q need a longer Delay Time. $\text{Delay Time (sec)} = \text{Expected Q} / \text{Frequency (Hz)}$ If measurements are not the same (not repeatable) when making multiple measurements, increase the Delay Time. NOTE This parameter contains the same information as the Settling Time parameter in the various measurement parameters screens. |
| Log Name | The name of the file that contains the measurement results. |
| Serial Name | An 8-character name used to uniquely describe a specific lot of crystals. |
| Serial # | The starting number used to uniquely identify the first crystal in a lot. The Serial Name and Serial Number are concatenated to create the final Part Number. A valid starting serial number is in the range 0-99999. For example, if Serial Name is TRANSAT and Serial # is 1, the reference number of the third part in the log file would be "TRANSAT_3". See Appendix G, "SAMPLE REPORTS" for more examples. |

| Parameter | Description |
|-----------|--|
| Report | <p>The type of report that is generated.</p> <p>Complete This report contains data for each item measured, and whether it passed or failed.</p> <p>Failure Only This report only contains data for each item measured that failed.</p> <p>Passed Only The report only contains data for each item measured that passed.</p> |
| Logging | Set to 1 to enable logging to a Log file, 0 disables logging. |
| Printing | Set to 1 to enable printing, 0 disables printing. |
| Distribs | Set to 1 to enable statistical distributions, 0 to disable. |

5.3.2 Fs Test Window (Series Frequency)

This test will check if the series frequency of the crystal is within the specified range.




Figure 5.5 Fs Test Window

The parameters in this screen (or the FL1 Test Window), as well as parameters in the Basic Test window, MUST be set before any tests or measurements are performed.)

WARNING If both the Fs and FL1 tests are enabled, one of the tests will fail.

The parameters in the Fs Test Window are described in the following table.

| Parameter | Description |
|--|--|
| Target Frequency | Frequency of the crystals to be measured. The maximum value for the CNA 200 is 200 MHz where the maximum value for a CNA 300 is 256 MHz. |
| Lower | The allowed frequency deviation below the Target Frequency. |
| NOTE The Lower parameter must be less than the Upper parameter. | |
| Upper | The allowed frequency deviation above the Target Frequency. |
| Units | The measurement units of the Lower and Upper parameters. Valid values are either ppm or KHz. |

5.3.3 R Test Window (Resistance)

This test will check if the resistance of the crystal is within the specified range.

| R Test | | | |
|--|-------|-------|----------|
| | Lower | Upper | Units |
| R | 1.0 | 20.0 | Ω |
| Press <input type="button" value="END"/> to accept changes, <input type="button" value="ESCAPE"/> to ABORT | | | |

Figure 5.6 R Test Window

The parameters in the R Test Window are described in the following table.

| Parameter | Description |
|-----------|--|
| Lower | The lowest resistance a crystal can have to pass this test. |
| Upper | The highest resistance a crystal can have to pass this test. |
| Units | Always set to ohms. |

5.3.4 L1 Test Window (Motional Inductance)

This test will check if the motional inductance of the crystal is within the specified range.

| L1 Test | | | |
|--|-------|-------|-------|
| | Lower | Upper | Units |
| L1 | 15.00 | 25.00 | mH |
| Press <input type="button" value="END"/> to accept changes, <input type="button" value="ESCAPE"/> to ABORT | | | |

Figure 5.7 L1 Test Window

The parameters in the L1 Test Window are described in the following table.

| Parameter | Description |
|-----------|---|
| Lower | The lowest motional inductance a crystal can have to pass this test. |
| Upper | The highest motional inductance a crystal can have to pass this test. |
| Units | Always set to mH. |

5.3.5 C1 Test Window (Motional Capacitance)

This test will check if the motional capacitance of the crystal is within the specified range.

| C1 Test | | | |
|--|--------|--------|-------|
| | Lower | Upper | Units |
| C1 | 10.000 | 15.000 | fF |
| Press END to accept changes, ESCAPE to ABORT | | | |

Figure 5.8 C1 Test Window

The parameters in the C1 Test Window are described in the following table.

| Parameter | Description |
|-----------|--|
| Lower | The lowest motional capacitance a crystal can have to pass this test. |
| Upper | The highest motional capacitance a crystal can have to pass this test. |
| Units | Always set to fF. |

5.3.6 C0 Test Window (Static Capacitance)

This test will check if the static capacitance of the crystal is within the specified range.

| C0 Test | | | |
|--|-------|-------|-------|
| | Lower | Upper | Units |
| C0 | 3.4 | 4.1 | pF |
| Press END to accept changes, ESCAPE to ABORT | | | |

Figure 5.9 C0 Test Window

The parameters in the C0 Test Window are described in the following table.

| Parameter | Description |
|-----------|--|
| Lower | The lowest static capacitance a crystal can have to pass this test. |
| Upper | The highest static capacitance a crystal can have to pass this test. |
| Units | Always set to pF. |

5.3.7 Q Test Window (Quality Factor)

This test will check if the quality factor of the crystal is within the specified range.

| Q Test | | | |
|--|-------|-------|-------|
| | Lower | Upper | Units |
| Q | 30.0 | 300.0 | /1000 |
| Press END to accept changes, ESCAPE to ABORT | | | |

Figure 5.10 Q Test Window

The parameters in the Q Test Window are described in the following table.

| Parameter | Description |
|-----------|--|
| Lower | The lowest quality factor a crystal can have to pass this test. |
| Upper | The highest quality factor a crystal can have to pass this test. |
| Units | Always set to Q/1000. |

5.3.8 SP Test Window (Spurious Search)

This test will look for spurs which occur past the main resonance (Target frequency) of the crystal.

| SP Test | | | |
|--|--------|-----|-----------|
| | Search | | Max Spur |
| | 20000 | ppm | -3.000 dB |
| Press END to accept changes, ESCAPE to ABORT | | | |

Figure 5.11 SP Test Window

The parameters in the SP Test Window are described in the following table. See Section 8.4.8 for parameters that configure how the Spurious Search test is performed.

| Parameter | Description |
|---------------|--|
| Search | The distance that spurs are searched for beyond the main resonance. |
| Max Spur (dB) | The maximum allowable amplitude relative to the main response. Spurious responses larger than this will fail this test. |
| Units | The measurement unit of the search parameter. Valid values are either in ppm or khz of the main resonance using the same boundary. |

5.3.9 DL Test Window (Drive Level)

This test determines and checks the change in frequency and resistance of the crystal at different drive levels

| DL Test | | | |
|--|-------------|-----------|----|
| Max delta R | Max delta F | Low Drive | |
| 20.0 % | 2.0 ppm | 1.000 | uW |
| Number of Pts | Delay | | |
| 50 | 5 msec | | |
| Press END to accept changes, ESCAPE to ABORT | | | |

Figure 5.12 DL Test Window

The frequency and resistance are measured from low to high drive. The Number of Pts parameter determines how many measurements are made.

The parameters in the DL Test Window are described in the following table.

| Parameter | Description |
|-------------------|--|
| Max Delta R (%) | Maximum allowable change in resistance over the specified drive level range. |
| Max Delta F (ppm) | Maximum allowable change in frequency over the specified drive level range. |
| Low Drive (uW) | Low-drive level setting. |

NOTE The DL Test uses the drive level setting from the Basic Test window as the high-drive level setting (see Section 5.3.1).

| | |
|---------------|---|
| Number of Pts | Number of measurements to make. The range is 0 to 100 points. |
| Delay (mSec) | Amount of time for the crystal to settle before each measurement. |

5.3.10 FL1 Test Window (Load Frequency)

The FL1, FL2 and FL3 tests are used to measure load frequencies at desired Target capacitances. The user can specify a different Target capacitance for each of the FL tests (FL1, FL2, FL3).

| FL1 Test | | | |
|--|------------------|----------------|---------------------|
| | Target Freq(MHz) | Target Cap(pF) | Min (ppm) Max (ppm) |
| FL1 : | 9.9982300 | 12.00 | -30.0 30.0 |
| Press END to accept changes, ESCAPE to ABORT | | | |

Figure 5.13 FL1 Test Window

In the FL1 test you specify a Target Load Frequency and the desired Target Capacitance.

In the FL1 test you specify a Target Load Frequency and the desired Target Capacitance.

WARNING If both the Fs and FL1 tests are enabled, one of the tests will fail.

The parameters in the FL1 Test Window are described in the following table.

| Parameter | Description |
|-------------------|--|
| Target Freq (MHz) | Expected load frequency of the crystal. The maximum value for the CNA 200 is 200 MHz where the maximum value for a CNA 300 is 256 MHz. |
| Target Cap (pF) | Desired Load capacitance. |
| Min (ppm) | Allowed frequency deviation below the Target Frequency. |
| Max (ppm) | Allowed frequency deviation above the Target Frequency. |

5.3.11 FL2 and FL3 Test Window (Load Frequency)

The FL1, FL2, and FL3 tests are used to measure load frequencies at desired Target capacitances. The user can specify a different Target Capacitance for each of the FL tests (FL1, FL2, FL3). The FL2 and FL3 test are identical to the FL1 test with the exception that they can be referenced relative to either the Target Frequency as specified in the FL1 test or the load frequency measured for the FL1 test.

| FL2 Test | | | | |
|--|-----------|----------------|-----------|-----------|
| | Reference | Target Cap(pF) | Min (ppm) | Max (ppm) |
| FL2 : | TARGET | 32.00 | -30.0 | 30.0 |
| Press END to accept changes, ESCAPE to ABORT | | | | |

Figure 5.14 FL2 Test Window

The parameters in the FL2 Test Window and FL3 Test Window are described in the following table.

| Parameter | Description |
|-----------------|---|
| Reference (MHz) | If set to TARGET, the system uses the Target frequency that was specified in the Fs or FL1 test. If set to FL1, the system uses the measured frequency from the FL1 test. |
| Target Cap (pF) | The expected load capacitance. |
| Min (ppm) | The lower limit for the Target frequency. |
| Max (ppm) | The upper limit for the Target frequency. |

5.3.12 C0/C1 Ratio Test

The C0/C1 test is used to measure the Ratio of C0 to C1




Figure 5.15 C0/C1 Ratio Test Window

The parameters in the C0/C1 is described in the following table.

| Parameter | Description |
|-----------|--|
| Lower | The lowest ratio of static capacitance a crystal can have to pass this test. |
| Upper | The highest ration of static capacitance a crystal can have to pass this test. |
| Units | None |

5.4 Starting a Test

After identifying the tests to perform, you can start the testing process.

To start testing

- Press <F1> to select the Start option.

The following screen is displayed while the tests are actually performed.

```

TRANSAT CNA-300 Crystal Measurement System U303 15:04:45
-----TEST SETUP : [ SYSFILE ]-----
Lot Name      : LOGFILE
Target Freq   : 9.9982300 Mhz
ESR           : 20.0 ohms
Drive Power   : 100.000 uW

Total 1
Pass 1 < 3 ppm pcs
Fail 0 < 7
Yld % 100.0 > 7 0

PASS

Test  Value      Unit  +Limit  -Limit  Failures
----  -
FS    9.9982284  MHz   -0.2    ppm     10.0    -10.0    0
R     16.2        ohm    20.0     1.0     0
C1    12.709      fF     15.0     10.0    0
L1    19.938      mH     25.0     15.0    0
Q     77.2        k      300.0    50.0    0
C0    3.8         pF     4.1      3.4     0
DLF   1.4         ppm    15.0     0
DLR   17.0        %      40.0     0
SP    3.0         %      3.0      0

Press SPACE to measure, U to view, R to retest, S for serial #, ESC to quit
    
```

Figure 5.16 Test Screen Containing Test Results

This screen contains the information you entered in the Test windows, and the information described in the following table.

| Parameter | Description |
|-----------|---|
| Total | The number of crystals that have been tested. |
| Pass | The number of crystals that have passed the tests. |
| Fail | The number of crystals that have failed the tests. |
| YLD% | The number of crystals that passed divided by the total number of crystals tested. |
| ppm | The limits for reporting test result distribution of Fs or FL1 for all parts which PASS. Three distribution limits are set and shown in the LOT STATUS box of the Test Screen. Distribution limits are set using the "Frequency Distribution Factor" (See Section 8.4.1, "System Parameters Screen"). Example, if Freq Dist Factor is set to 0.33 and the test spec for Fs is +/-10 ppm, the first distribution limit is calculated $0.33 \times +/-10\text{ppm} = +/-3\text{ppm}$. The second distribution limit is calculated $0.66 \times +/-10\text{ppm} = +/-7\text{ppm}$. |
| pcs | The number of crystals that test within the limits defined in ppm described above. |

To measure a crystal

1. Place the next crystal in the Pi Network.
2. If the CNA is in Manual mode, press <SPACE>.

If the CNA is in Automatic mode, do NOT press anything.

(See Section 8.4.1 for information about Manual and Automatic modes.)

Continue repeating the above steps until all crystals have been tested. The information displayed after each test is described in the following table.

| Parameter | Description |
|-----------|---|
| PASS/FAIL | Either PASS or FAIL displays after a test is run, indicating whether the crystal just tested was within the limits specified. |
| Test | The name of each test you selected in the Current Test screen. |
| Value | The value that was measured for the current crystal. |
| + Limit | The upper limit that you specified for each test. |
| - Limit | The lower limit that you specified for each test. |
| Failures | The number of crystals that have been tested in this lot that have failed tests. |

To view the results of previous tests

- Press the <V> key.

NOTE Only the test results from the current lot is displayed.

To re-test the same crystal

- Press the <R> key.

This function is useful when a crystal fails due to improper insertion into the PI Network. This causes the last results recorded in the Log file to be overwritten with the results of the re-test, if logging is enabled.

To display or modify the serial number

- Press the <S> key. To modify the serial number, simply type in the new value and press ENTER.

This function is useful when non-sequential serial numbers are needed.

To stop testing

- Press the <ESC> key. A dialog box will appear warning you that the operation is about to be aborted. Press <ESC> again to return to the Main menu.

6 SETUP TEST

Setup Tests define the method of testing for specific types of crystals. Each Setup Test contains everything the system needs to know to measure a group of crystals. To run a test, all you need to do is load the appropriate Setup Test and provide Lot information.

A Setup Test contains:

- The list of tests you want performed on a type of crystal and each test's parameters.
- The measurement parameters that describe how to measure this type of crystal.
- The types of reports you want generated from the test results.

This chapter describes how to create and modify Setup Tests. The first screen you will see after you select Setup Test from the Main menu is the Setup Test screen described in the following section.

6.1 Creating and Modifying Setup Tests

The Setup Test screen allows you to create, modify, and delete Setup Tests and the information contained in them.

```

TRANSAT CNA-300 Crystal Measurement System U3.03          09:00:40
< Setup Test >

CURRENT TEST SETUP : SYSFILE      PATH:

----- Test List -----
DP: 100.000  $\mu$ W  ESR: 5.0  $\Omega$   Delay: 5 msec Log: 1  Prt: 0  Dst: 1
FS = 9.9970000 MHz within 0.000 ppm and 301.000 ppm
FLi= 9.9970000 MHz @10.00 pF within 0.0 ppm and 301.0 ppm
R = within 19.0  $\Omega$  and 32.0  $\Omega$ 
Li = within 0.00 mH and 200.00 mH
Ci = within 0.000 fF and 10.000 fF
C0 = within 3.4 pF and 4.1 pF
SP = search 2 ppm and mark spurs  $\geq$  3.000 dB
  
```

F1 START F2 MODIFY F3 MEASPAR F4 LOAD F5 SAVE F6 CREATE F7 DELETE F8 F9

Figure 6.1 Setup Test Screen

In this screen you can make a Test List as explained in Section 5.1, "Specify a Test Setup". You can also specify how to make crystal measurements (see Section 6.7, "Modifying Measurement Parameters"). The following table describes the options available from this screen.

| Option | Description |
|------------|--|
| <F1> Start | Choosing this parameter causes the Test screen to display. Tests and measurements are performed from the Test screen. The Test screen is described in Section 5.4. |

| Option | Description |
|--|--|
| <F2> Modify | <p>This option allows:</p> <ul style="list-style-type: none"> ■ Starting a Test ■ Editing a Test in the Test List ■ Adding a test to the Test List ■ Deleting a test from the Test List ■ Deleting all Test <p>When selected, another menu appears at the bottom of the screen. These menu selections are described in section 5.3.</p> |
| <F3> MeasPar | Choosing this option causes the Measurement Parameter screen for the selected measurement type to display. The different measurement parameter screens are described in Appendix A, "MEASUREMENT TYPES". |
| <F4> Load | Choosing this option allows another setup to be loaded. This screen is described in section 6.2. |
| <F5> Save | Choosing this option causes all changes you made to the current test Setup file to be saved. |
| <hr/> <p>NOTE If you exit the Setup Test screen without selecting this option, all changes you made are lost.</p> <hr/> | |
| <F6> Create | Choosing this option allows a setup to be created. This screen is described in section 6.4. |
| <F7> Delete | Choosing this option allows a setup to be deleted. This screen is described in section 6.5. |

6.2 Load Setup Test

From the Setup Test menu, you can load Setup Tests by pressing <F4>.

```

TRANSAT CNA-300 Crystal Measurement System V3.01          13:32:53
< Load Test Setup >

```

Setup To Load : ██████████

Enter Name, or press ENTER for list

Figure 6.2 Load Setup Screen

To load a Setup Test

1. Press <F4>
2. Type in the name of the Setup Test.

To load a predefined (or saved) Setup Test, press <ENTER>. A list of all saved Setup Tests is displayed. Use the Up- and Down-Arrow Keys to select from the list of Setup Tests.

3. Press <ENTER>.

6.3 Save Setup Test

From the Test Setup screen, you can save Setup Tests.

To save the current Setup Test

- Press <F5>.

All changes are saved to the current Setup Tests.

6.4 Create Setup Test

From the Test Setup screen, you can create Setup Test.

```

TRANSAT CNA-300 Crystal Measurement System U3.01          09:14:09
< Create Test Setup >

```

```

          Define System File
SYSTEM FILE NAME : 
Press * for LIST, F1 for HELP, ESC to EXIT

```

Enter new file name or * for directory

Figure 6.3 Create a Setup Test.

To create a Setup Test

1. Press <F6>.
2. Type in the name of the Setup Test to create.

NOTE The name of the Setup Test must be unique. Otherwise, the system will ask if you want to load it or save (overwrite) it. If you choose to load it, any changes you made are lost!

To see a list of Setup Tests currently defined, press * (asterisk) and then <ENTER>.

3. Press <ENTER>.

6.5 Delete Setup Test

From the Test Setup screen, you can delete Setup Tests.

```
TRANSAT CNA-300 Crystal Measurement System U3.01 09:17:36
< Delete Test Setup >
```

Select Test Setup To Delete: ██████████

Enter Name, or press ENTER for list

Figure 6.4 Delete Setup Test

To delete a Setup Test

1. Press <F7>.
2. Type in the name of the Setup Test.

To delete a predefined (or saved) Setup Test, press <ENTER>. A list of all saved Setup Tests is displayed. Use the Up- and-Down-Arrow Keys to select from the list of Setup Tests.

3. If you are sure that you selected the Setup Test to delete, press <ENTER>. Otherwise, press <ESCAPE> to abort the delete command.

WARNING Once the Setup Test is deleted, there is no way to recover it!


6.6 Modifying Measurement Parameters

The system can measure crystals using different methods. Each Setup Test specifies the type (method) of measurement to use for testing. The type of measurement selected is typically based on the user's test requirements and the characteristics of the device to be tested. The following section describes how to select a measurement type and modify its associated parameters. Appendix A, "MEASUREMENT TYPES" explains the different measurement types in more detail.

NOTE Depending on the measurement type selected, you will have different parameters displayed. The following procedure is based on selecting the Standard Parameter measurement.


To select the measurement type and modify its parameters

1. Press <F3>.
2. Press <SPACE> to display a list of measurement types.



Press <SPACE> to select, then <RETURN> to confirm or <ESCAPE> to abort

Figure 6.5 List of Measurement Types(CNA 300)



Press <SPACE> to select, then <RETURN> to confirm or <ESCAPE> to abort

Figure 6.6 List of Measurement Types (CNA 200)

3. Select the desired measurement type by using the Up- and Down-Arrow Keys. For example, highlight Standard Par, and then press <ENTER>.

The parameter screen for Standard Parameter displays.




Figure 6.7 Standard Crystal Parameters Screen (CNA 300)




Figure 6.8 Sweep Crystal Parameters Screen (CNA 200)

4. Use the arrow keys to move between parameters and modify the parameters as desired.
5. When you are done, press <END> to accept the parameters as shown. Otherwise, press <ESC> to abort any changes.

If you selected one of the following measurement types Standard Par, Special Par, Multi Point, or Sweep Meas, the Load Capacitance Measurement Parameters window will appear. If you are testing for loaded frequency (FL1, FL2, or FL3) modify parameters as described per Section 6.4, "Modifying Load Capacitance Measurement Parameters". If no loaded frequency tests are selected, press <END> to accept the changes and return to the Setup Test screen.

6.7 Modifying Load Capacitance Measurement Parameters

The system is capable of performing measurements of the crystal in series with a capacitive load when Standard Parameter, Special Parameter, Multi Point, or Sweep Measurement is selected. Please refer to Appendix B, "LOAD CAPACITANCE MEASUREMENTS" for a detailed description of the different methods of calculating load frequency.

To modify the load capacitance parameters

1. From the Setup Test screen, press <F3> to choose MEASUREMENT PARAMETERS. After modifying the measurement parameters, the Load Capacitance Measurement Parameters screen displays.
2. Modify the Measurement Parameters as described in Section 6.7. Press <END> when done.

The Load Capacitance Measurement Parameters screen appears.

Figure 6.9 Load Capacitance Measurement Parameters Screen

3. Use the arrow keys to highlight Load CL Mode and press <SPACE>.

A list of the available CL modes are listed. The following table briefly describes the different methods of making load capacitance measurements. See Appendix B, "LOAD CAPACITANCE MEASUREMENTS".

| CL Mode | Method |
|--------------------------------------|---|
| Physical | Uses a physical load capacitor to make measurements. |
| Numerical | Mathematically calculates Load frequency without the use of a Load capacitor. |
| EQREACT (Equivalent Reactance) | Uses reactance slope to calculate the Load frequency without the use of a Load capacitor. |

NOTE To use any of these methods, the FL1, FL2, or FL3 test must be selected.

4. Use the arrow keys to highlight the desired Load CL Mode and press <ENTER> to select it.

If Load CL Mode is set to Physical, then enter the value of the insert capacitor placed in the PI Network in the Insert Cap field. For Numerical or EQREACT modes, set Insert Cap to 0.

5. When you are finished, press <ENTER> to accept the Load Capacitance Parameters.

7 WORKING WITH DATA FROM PREVIOUS TESTS

Data from previous test runs can be viewed, printed, or exported to a dBASE compatible file at a later time from the View Data menu. The system also has the ability to regenerate a test report based on a different set of test specifications. The following sections describe how to do the following:

- Review test data from previous test runs.
- Review distribution data.
- Regenerate test reports based on specifications other than those defined when the test was run.
- Export data to dBASE compatible formatted files.
- Delete old test data.

To access the View Data Menu

- From the Main Menu, press <3> to choose VIEW DATA.

```

TRANSAT CNA-300 Crystal Measurement System U3.01          09:43:32
< View Data Menu >
CURRENT DATA SET: LOGFILE

ENTER SELECTION : [ █ ]      1. SELECT DATA SET
                               2. DISPLAY DATA
                               3. PRINT DATA
                               4. DISPLAY DISTRIBUTIONS
                               5. PRINT DISTRIBUTIONS
                               6. MODIFY TEST SPECIFICATIONS
                               7. RE-GENERATE TEST REPORT
                               8. EXPORT DATA SET
                               9. DELETE DATA SET

```

Figure 7.1 View Data Menu

7.1 Review Test Data from Previous Test Runs

Test data is collected and saved in Log Files referenced by the Lot Name assigned when the test was run. (See Section 5.2).

To select data from a previous test run

1. Press <1> to choose SELECT DATA SET.
2. Type in the name of the data set to view.

To view a list of all saved Log Files, press <ENTER>. Use the Up- and Down-Arrow Keys to select the Log File from the list.

3. Press <ENTER>.

Results from the selected Log File can now be displayed, printed, exported, etc... using functions in the View Data Menu.

To display the test data

- Press <2> to choose DISPLAY DATA.

You can use the arrow keys, <PgUp>, <PgDn>, <Home>, and <End> keys to view the data. Press <ESC> when you are finished.

To print the test data

- Press <3> to choose PRINT DATA.

The test data printed to the printer is in the same format as displayed on the screen.

7.2 Review Distribution Data

To display distribution charts

- Press <4> to choose DISPLAY DISTRIBUTIONS.

A distribution chart for each test selected is displayed one at a time. Press <ESC> to display the next distribution chart.

NOTE Distributions will only be displayed if the *Distribs* parameter is set to 1 in Basic Test when the test report is generated! You can regenerate a test report later with the *Distribs* parameter set to 1 to cause the system to generate distribution charts. (See Section 7.3)

To print distribution charts

- Press <5>.

The distribution charts for each of the selected tests is printed.

7.3 Regenerate Test Reports

To regenerate a test report based on modified test specifications

1. Press <6> to choose MODIFY TEST SPECIFICATIONS.

See Section 5.3, "Modifying the Current Test Setup" for information on how to add, modify, and delete tests.

2. Press <7> to regenerate the test report based on the modified test specifications.

You will be prompted to enter a new Log File name for storing the modified test results. A new Log File name must be given in order to regenerate the test report.

7.4 Export Data

To export test data to dBASE format

- From the View Data menu, press <8> to choose EXPORT TEST DATA.

The system will create a lot information file (.DBL) and an individual measurement file (.DBF) based on the currently selected test data. An index file (.CDX) is also created for the individual measurement file. All three files have the same name as the selected test data and are stored in the directory specified by the External Report File Path parameter described in Section 8.4.6.

If the files already exist, you are asked if you want to overwrite them. Press <1> to overwrite, or any other key to abort the process.

7.5 Delete Old Test Data

To delete test data

1. From the View Data menu, press <9> to choose DELETE LOG FILE.
2. Type in the name of the data set to delete.

To view a list of the test data to delete, press <ENTER>. Use the Up- and Down-Arrow Keys to select the Log File from the list. Press <ENTER> to select it.

3. Press <ENTER> to confirm, or press <ESC> to abort the procedure. This last step avoids accidentally deleting test data.

WARNING Once the test data is deleted, it can not be recovered!

8 CONFIGURING THE SYSTEM

This chapter describes how to do the following:

- Calibrate the instrument to correct for variations in phase and amplitude over its operating range.
- Setup how reports are printed and/or saved in log files.
- Perform quick measurements for fast analysis of crystal characteristics.
- Setup system specific parameters (other than crystal parameters).

To configure the system

- From the Main Menu, press <4> to choose CONFIGURE SYSTEM. The Configure System menu is displayed.

```

TRANSAT CNA-300 Crystal Measurement System U3.01 09:50:43
< Configure System Menu >

ENTER SELECTION : [ █ ]
1. CALIBRATE INSTRUMENT
2. PRINT/LOG FILE MAINTENANCE
3. QUICK MEASURE MODE
4. INTERNAL PARAMETERS

```

Figure 8.1 Configure System Menu

8.1 Calibrating the Instrument

The system must be calibrated to correct for variations in phase and amplitude over the operating frequency range of the instrument. The calibration data is stored and used for all measurement calculations. The calibration need only be performed periodically as part of a regular maintenance cycle or when changes or modifications are made to the tooling used with the instrument (cables, PI Network, etc.).

You will need the following to perform the calibration:

- A Reference Short.
- A Reference Resistor (approx. 50 ohms).

The system prompts when to place them in the PI Network at the appropriate time.

NOTE If you have a PI Network that has a Load Capacitance socket (i.e. TFP-6L), insert a short (supplied with the system) in the Load Capacitance socket before beginning the calibration.

To perform a calibration

1. From the Configure System menu, press <1>.
The Short Circuit Calibration window is displayed.




Figure 8.2 Short Circuit Calibration Window

2. Place the Reference Short into the PI Network and press <ENTER>.

NOTE Pressing <ESC> at any time during calibration will abort the process and the system will revert to the last successful calibration.

This window displays:




Figure 8.3 Calibration - Step 1

After the Short Circuit calibration completes, the Resistor calibration begins. The following window displays:




Figure 8.4 Resistor Calibration Window

3. Place the Calibration Resistor in the PI Network. Press any key (other than <ESC>) to continue the calibration.
This screen displays:




Figure 8.5 Calibration - Step 2

After the Resistor calibration completes successfully, the Calibration Complete window is displayed.




Figure 8.6 Calibration Complete

If the calibration is aborted, the system will display the Calibration Failed screen and revert to the last successful calibration.




Figure 8.7 Calibration Aborted

4. Press any key to return to the Configure System menu.

8.2 Setting Up How Reports are Printed and/or Saved in Log Files

The measurement system has very flexible reporting capabilities. The following list briefly describes the capabilities available:

- System reports can be sent to a printer and/or saved to a log file.
- Automatically name the log file (based on today's date).
- Automatically delete log files that are older than a specified number of days.
- Choose from three standard report types (COMPLETE, PASS ONLY, or FAIL ONLY).
- Use a Custom Report Script for flexibility in making your own report.
- Use an external program to generate a report (maximum flexibility).

To go to the Print/Log Setup Menu

1. From the Main Menu, press <4> to choose CONFIGURE SYSTEM.
2. Press <2> to choose PRINT/LOG FILE MAINTENANCE.

The Print/Log File Maintenance Menu is displayed.

```

TRANSAT CNA-300 Crystal Measurement System U3.03 12:54:38
< Print/Log Setup Menu >

ENTER SELECTION : [ █ ]  1. MODIFY SETUP           4. DELETE LOG FILE
                        2. VIEW LOG FILE          5. SELECT SCRIPT FILE
                        3. PRINT LOG FILE         6. SELECT EXTERNAL FILE

===== [ Print/Log Parameters ] =====
Automatic Delete (1=ON) : 1      Auto File Name (1=ON) : 0
# of Days before Delete? : 30
Enable Logging (0/1)?    : 1      Printing (0/1)?      : 0
Log File Name           : LOGFILE
Standard Report Format   : COMPLETE
                        Custom Reporting Setup -----
Custom Reports (0/1)?   : 0
Script File Name        : STANDARD
                        External Reporting Setup -----
External Reports (0/1)? : 0
External Report Name    : MULTICOL
  
```

Figure 8.8 Print/Log Setup Menu

8.2.1 Modifying the Print/Log Setup

You can enable and/or modify any of the report(s) and/or functions listed in the Print/Log Parameters screen by selecting the Modify Setup option.

To modify the setup

1. From the Print/Log Setup menu, press <1>.
2. Use the arrow keys to highlight the parameter to modify. When you are done modifying parameters, press <ESC> to return to the Print/Log Setup menu.

The following table describes the parameters that can be modified.

| Parameter | Description |
|-------------------------|---|
| Automatic Delete | When enabled, this option deletes all Log files older than the value entered in the # of Days before Delete parameter. 1 enables this option, 0 disables this option. |
| # of Days before Delete | The number of days from the current date to delete Log files if the Automatic Delete parameter is enabled. |
| Enable Logging | Set this to 1 to enable logging of measurement results, 0 to disable it. The Log File Name parameter specifies the name of the file the measurement results are saved in. |
| Log File Name | This, combined with the Log File Path parameter (See section 8.4.6, "Parameter File Paths Screen"), specifies the file name of the Log file used to save measurement results. The file name can be up to 8 characters. |

| Parameter | Description |
|------------------------|--|
| Standard Report Format | The report format used when logging and printing results. COMPLETE: Prints, and/or logs, all results. FAILURE ONLY: Prints, and/or logs, only the results of crystals that fail any selected measurement parameters. PASS ONLY: Prints, and/or logs, only the results of crystals that pass all selected measurement parameters. |
| Custom Reports | Enabling this option allows you to customize your reports using a template. See Appendix E, "CREATING CUSTOM REPORTS USING SCRIPT FILES". Set this to 1 to enable custom reports, 0 to disable it. |
| Script File Name | The name of the Custom Report Script File you created to perform custom reports. This can be a maximum of 8 characters long. |
| External Report | Set this to 1 to enable external reports, 0 to disable it. |
| External Report Name | The name of the batch file (external report) you created. The name can be a maximum of 8 characters long. |

8.2.2 Viewing Log Files

You can view the current log file or choose from a list of log files available.

To view the current log file

1. From the Print/Log Setup menu, press <2>.
2. Use the Up- and Down-Arrow Keys to highlight `Current File` and press <ENTER>.

You can use the Up- and Down-Arrow Keys, <PgUp>, <PgDn>, <Home>, and <End> keys to view the data. Press <ESC> when you are finished.

To view a log file other than the current

1. From the Print/Log Setup menu, press <2>.
2. Use the Up- and Down-Arrow Keys to highlight `List Files ...` and press <ENTER>.
3. Use the Up- and Down-Arrow Keys to highlight the log file to view and press <ENTER>.

You can use the arrow keys, <PgUp>, <PgDn>, <Home>, and <End> keys to view the data. Press <ESC> when you are finished.

8.2.3 Printing Log Files

You can print the current log file or choose from a list of log files available. The log file is printed to the printer attached to LPT1.

To print the current log file

1. From the Print/Log Setup menu, press <3>.

2. Use the arrow keys to highlight `Current File` and press `<ENTER>`.

To print a log file other than the current

1. From the Print/Log Setup menu, press `<3>`.
2. Use the Up- and Down-Arrow Keys to highlight `List Files ...` and press `<ENTER>`.
3. Use the Up- and Down-Arrow Keys to highlight the log file to print and press `<ENTER>`.

8.2.4 Deleting Log Files

You can delete the current log file or choose from a list of log files available.

To delete the current log file

1. From the Print/Log Setup menu, press `<4>`.
2. Use the Up- and Down-Arrow keys to highlight `Current File` and press `<ENTER>`.
3. Press `<ENTER>` to confirm, or press `<ESC>` to abort the procedure. This last step avoids accidentally deleting the log file.

WARNING Once the log file is deleted, it can not be recovered!

To delete a log file other than the current

1. From the Print/Log Setup menu, press `<4>`.
2. Use the Up- and Down-Arrow Keys to highlight `List Files ...` and press `<ENTER>`.
3. Use the Up- and Down-Arrow Keys to highlight the log file to delete and press `<ENTER>`.
4. Press `<ENTER>` to confirm, or press `<ESC>` to abort the procedure. This last step avoids accidentally deleting the log file.

WARNING Once the log file is deleted, it can not be recovered!

8.2.5 Selecting a Custom Report Script File

Using your own Custom Report Script allows you to tailor the report to include only the information that you need.

A Custom Report Script File called STANDARD is provided with the measurement system. This is an example of what can be done using the custom reporting capability of the system. The format for each data item is defined using a "C" language printf style. For more information on creating a Custom Report Script, see Appendix E, "CREATING CUSTOM REPORTS USING SCRIPT FILES".

To select a custom report script file

1. From the Print/Log Setup menu, press `<5>`.

2. Enter the name of the script file to use and press <ENTER>.

To choose from a list of available script files, press * (asterisk) and <ENTER>. Use the Up- and Down-Arrow Keys to highlight the script file and press <ENTER>.

NOTE You must enable custom reports by setting the *Custom Reports* parameter to 1. (See Section 8.2.1, "Modifying the Print/Log Setup".)

8.2.6 Selecting an External Report

We provide a facility to save all measurement data in dBASE format and run an external program to generate a report. This allows you to use one of many commercially available products (i.e. Microsoft FoxPro, R&R XBase Edition for DOS from Concentric Data Systems, etc...) that can read dBASE files to generate a report. Using an external program to generate a report is the most flexible method, but requires you to purchase a separate program to generate the report.

External reports are batch files that you create that are automatically run after a production test ends. The batch file is a single line MS-DOS batch file with a ".EXT" file extension. An example method using the R&R Report Writer® is described in Appendix D, "USING R&R REPORT WRITER® TO CUSTOMIZE REPORTS".

To select an external report

1. From the Print/Log Setup menu, press <6>.
2. Enter the name of the external report to use and press <ENTER>.

To choose from a list of available external reports, press * (asterisk) and <ENTER>. Use the Up- and Down-Arrow Keys to highlight the report and press <ENTER>.

NOTE You must enable external reports by setting the *External Reports* parameter to 1. (See Section 8.2.1, "Modifying the Print/Log Setup".)

8.3 Quick Measurement Screen

The Quick Measurement screen is intended to be used as an engineering tool for quick evaluation of device characteristics.

To access the Quick Measurement Screen

1. From the Main Menu, press <4> to choose CONFIGURE SYSTEM.
2. Press <3> to choose QUICK MEASURE MODE.

The Quick Measurement Screen is displayed.




Figure 8.9 Quick Measurement Screen (CNA 300)




Figure 8.10 Quick Measurement Screen (CNA 200)

The Quick Measurement screen is divided into three major sections:

- A Status line at the top of the screen that shows the status of the CNA.
- A menu section in the middle of the screen.
- Current setup parameters at the bottom of the screen.

8.3.1 Status Line



Figure 8.11 Status Line of the Quick Measure Screen (CNA 300)



Figure 8.12 Status Line of the Quick Measure Screen (CNA 200)

The Status line in the Quick Measurement screen displays the following information about the status of the CNA measurement system:

- Current device or instrument frequency measured (in MHz).
- Displays the A and B channel voltages in millivolts and the raw phase meter measurement in degrees.
- Shows the sweep begin and end frequencies (in MHz).
- Indicates that the Phase Locked Receiver is operating properly when PLR displays 'LOCK' (CNA 300).
- ALM indicates 'LOCK' when the system is phase locked to a crystal, or when the phase offset between A and B channels is close to the targeted phase angle (CNA 300).

8.3.2 Measurement Menu

The menu section, located in the middle of the Quick Measurement screen, is illustrated in the following figure.




Figure 8.13 Menu Section of Quick Measurement Screen

The following table briefly describes the menu choices in the Quick Measurement menu.

| Option | Description |
|------------------|--|
| Make Measurement | Triggers the actual measurement. See Appendix A, "MEASUREMENT TYPES" for more detailed information on each measurement type. |

| Option | Description |
|------------------------|---|
| Change Current Setup | Allows the operator to modify the Current Setup parameters at the bottom of the Quick Measurement Screen. When selected, the cursor is moved to the <i>Frequency</i> parameter in the Current Setup parameters section. |
| Measurement Parameters | Displays the Measurement Parameters Screen associated with the currently selected measurement type. See Appendix A, "MEASUREMENT TYPES" for more detailed information on each measurement type. |
| Sweep Control | Displays the Phase Lock Control menu for the CNA 300. For the CNA 200, activation displays a menu to set the sweep begin and end. |
| Display Sweep | Performs the Sweep measurement. After the sweep has completed, the selected plots display. |
| Sweep Parameters | Allows the operator to modify the sweep parameters. See Section 8.3.4, "Modifying How a Sweep Measurement is Made" for information. |
| File Maintenance | Causes the Quick Measure File Maintenance menu to display. |
| Internal Parameters | Displays the Internal Parameters menu. See Section 8.4, "Modifying Internal Parameters" for more information. |

8.3.2.1 Using the Sweep Control Menu

While in the phase lock mode, you can manually control the sweep begin and sweep end frequencies.

To set a new sweep begin frequency

1. From the Quick Measurement menu, press <4>.
2. Press <1>.
3. Enter a new sweep begin frequency (in MHz) and press <ENTER>.

The new sweep begin frequency is displayed in the Quick Measurement Status Line.

NOTE The sweep limits are limited to the frequency ranges of the measurement instrument. For example, if the SWEEP BEGIN is changed to 18,0000 MHz, the SWEEP END is automatically adjusted to 31.9990 MHz.

The frequency ranges are (in MHz):

- 128 - 256 (128 - 200 for the CNA 200)
- 64 - 128
- 32 - 64
- 16 - 32
- 8 - 16
- 4 - 8
- 2 - 4
- 1 - 2

To set a new sweep end frequency

1. From the Quick Measurement menu, press <4>.
2. Press <2>.
3. Enter a new sweep end frequency (in MHz) and press <ENTER>.

The new sweep end frequency is displayed in the Quick Measurement Status Line.

NOTE The sweep limits are limited to the frequency ranges of the measurement instrument. For example, if the SWEEP END is changed to 18.0000 MHz, the SWEEP BEGIN is automatically adjusted to 15.6800 MHz.

To go to sweep begin (CNA 300 only)

1. From the Quick Measurement menu, press <4>.
2. Press <3>.

The measurement instrument will go to the sweep begin frequency displayed in the status line of the screen.

To go to sweep end (CNA 300 only)

1. From the Quick Measurement menu, press <4>.
2. Press <4>.

The measurement instrument will go to the sweep end frequency displayed in the status line of the screen.

8.3.2.2 Modifying the Current Setup

The Current Setup Parameters section, located on the bottom of the Quick Measure screen, is illustrated in the following figure.

```

===== [ SETUP FILE : SYSFILE ] ===== [ LOG FILE : LOGFILE ] =====
FREQ : 9.9970000 MHz MEASUREMENT: Sweep Meas CL MODE : SERIES
ESR : 13.0 Ω DRIVE POWER: 100.000 uW ACTUAL CL : 12.00 pF
GATE : 100 msec LOW DRIVE : 1.000 uW FL1 [0] : 10.00 pF
HIGH Q [0] LOGGING [0] FL2 [0] : 32.00 pF
ANGLE : 70.00 degrees PRINTING [0] FL3 [0] : 0.00 pF
=====
    
```

Figure 8.14 Current Setup Parameters (CNA 300)

```

===== [ SETUP FILE : SYSFILE ] ===== [ LOG FILE : LOGFILE ] =====
FREQ : 9.9970000 MHz MEASUREMENT: Sweep Meas CL MODE : SERIES
ESR : 13.0 Ω DRIVE POWER: 100.000 uW ACTUAL CL : 12.00 pF
GATE : 100 msec LOW DRIVE : 1.000 uW FL1 [0] : 10.00 pF
HIGH Q [0] LOGGING [0] FL2 [0] : 32.00 pF
PRINTING [0] FL3 [0] : 0.00 pF
=====
    
```

Figure 8.15 Current Setup Parameters (CNA 200)

The following table describes the parameters that can be modified.

| Parameter | Description |
|--------------------|--|
| Freq (MHz) | The Target Frequency of the crystal. The frequency can be set anywhere in the operating range of the instrument: <ul style="list-style-type: none"> ■ CNA 300: 1.0 to 256 MHz ■ CNA 200: 1.0 to 200 MHz |
| ESR (Ohm) | Expected series resistance. |
| Gate (mSec) | Sets the frequency counter gate time. The gate affects the accuracy of the selected measurement. For maximum accuracy in measurements, the gate time should be set to 1000 mSec (1 sec). The resolution of the frequency measurements made with each gate setting is (approximately): <ul style="list-style-type: none"> ■ 1000 mSec - 0.0025 ppm ■ 100 mSec - 0.025 ppm ■ 10 mSec - 0.25 ppm ■ 1 mSec - 2.5 ppm |
| High Q | Set to 1 to enable slow sweep. Used for measuring higher Q (>500K) crystals. |
| Angle (deg) | Sets the phase lock angle for the system. Valid values are from 0 to 90 degrees. |
| Measurement | Selects the measurement type to use. The options are: <ul style="list-style-type: none"> ■ Frequency ■ Freq & Resist ■ Standard Par ■ Special Par ■ Multi Point ■ Sweep Meas ■ Ph Locked Im ■ Freq Locked Im ■ Insert Cap ■ Spur Search ■ DLD Sweep ■ Calculate CL <p>See Appendix A, "MEASUREMENT TYPES" for more information.</p> |
| Drive Power (uW) | Sets the drive power applied to the device, based on ESR. |
| Low Drive (uW) | The low-drive level for the Drive Level test (if Drive Level test is enabled). |
| Printing | Enable/disable printing the test results to a printer. Enter 0 to disable, 1 to enable. |
| Logging | Enable/disable logging the test results to a file. Enter 0 to disable, 1 to enable. |
| CL Mode | Selects Series or Load Capacitance measurement. The various Load Capacitance Measurements are described in Appendix B, "LOAD CAPACITANCE MEASUREMENTS". |
| Actual CL (pF) | The physical insert capacitance inserted in the Pi Network during measurements. |
| FL1, FL2, FL3 (pF) | Multiple target load capacitance values. |

8.3.3 Performing a Sweep Measurement

- From the Quick Measurement menu, press <5>.

A status line at the bottom of the screen is updated as the sweep is made. After completing the sweep, the results are graphically displayed. You can plot the graph(s) to a printer by pressing <P>. Press <ESC> when you are finished viewing the sweep results.

8.3.4 Modifying How a Sweep Measurement is Made

To modify a sweep measurement

- From the Quick Measurement menu, press <6>.

```

TRANSAI CNA-300 Crystal Measurement System 03.03 10:41:42
ENTER SELECTION : [ 1 ] 1. MODIFY PLOT SETUP      4. SAVE PLOT SETUP
                    2. MODIFY PRINTER SETUP
                    3. DISPLAY PLOT

===== [ PLOT SETUP ] =====
# PTS : 100 START/STOP (MHz): 1.000000 2.000000 A DRIVE (mV): 100.0
                    DWELL TIME (msec): 0 PHASE SWEEP : 0
----- [1]----- [2]----- [3]----- [4]-----
TYPE: Phase vs Freq B/A vs Freq No Display No Display
POS: UPPER HALF LOWER HALF LOWER LEFT SIDE LOWER RIGHT SIDE
'X' CTRL: AUTO SCALE AUTO SCALE AUTO SCALE AUTO SCALE
    AXIS: LIN LIN LIN LIN
    MIN: 0.000000 0.000000 0.000000 0.000000
    MAX: 0.000000 0.000000 0.000000 0.000000
'Y' CTRL: AUTO SCALE AUTO SCALE AUTO SCALE AUTO SCALE
    AXIS: LIN LIN LIN LIN
    MIN: 0.000000 0.000000 0.000000 0.000000
    MAX: 0.000000 0.000000 0.000000 0.000000
    
```

Figure 8.16 Sweep Measurement Menu

The following table briefly describes each menu choice.

| Option | Description |
|-------------------------|---|
| 1. Modify Plot Setup | Change the setup parameters for performing a sweep measurement. |
| 2. Modify Printer Setup | Allows the operator to modify the type of printer and certain parameters associated with the printer. Remember these printer definitions are only used for printing the graphic images from the sweep measurement mode. |
| 3. Display Plot | Start the sweep measurement function. After the sweep is complete, the selected plot(s) will display. |
| 4. Save Plot Setup | Save all current values displayed in the Plot Setup box except Start/Stop Frequencies and A Drive. |

To make a frequency sweep measurement, you must specify the start and stop frequencies. The default values are taken from the sweep begin and sweep end frequencies displayed on the Status Line of the Quick Measurement screen. You can also specify a dwell time per point to help stabilize the measurements. The system also can make a phase sweep measurement where the frequency is held constant while the phase is swept.

To modify the sweep measurement parameters

1. From the Quick Measurement menu, press <6> to choose SWEEP PARAMETERS.
2. Press <1> to modify the plot setup. Use the arrow keys to highlight the parameter to change. The following table describes the parameters available. Press <ESC> when you are finished making changes.

| Parameter | Description |
|---------------------------|---|
| # Points | The number of points measured to generate the desired plot. |
| Start/Stop (MHz) | The frequency sweep range for the sweep measurement. |
| A Drive (mV) | The drive level setting in mV for the sweep measurement. |
| Delay (mSec) | Amount of time to delay before each measurement in the sweep. |
| Phase Sweep | Starts a special mode of sweep operation that continuously samples the frequency while the CNA is performing a phase lock sweep. |
| Type | The type of plot to be displayed (phase vs. freq, B vs. freq, etc.). |
| POS | The area of the screen to display the plot. Up to four different plots may be displayed at the same time. |
| 'X' Control ('Y' Control) | The type of scaling to be applied to the 'X' ('Y') axis. <p>MANUAL SCALE: In this mode the user may enter the X and Y values to be used as the maximum and minimum values for the plot. The plot is scaled according to these values.</p> <p>AUTO SCALE: In this mode, the plot data will be used to determine the maximum and minimum values for each axis, and then the graph is scaled accordingly.</p> |
| Axis | The measurement display type: LIN (linear) or LOG (logarithmic). |
| Min | Minimum value for the 'X' or 'Y' axis. It is not necessary to enter a value here if the corresponding Scale Control is set to AUTO. |
| Max | Maximum value for the 'X' or 'Y' axis. It is not necessary to enter a value here if the corresponding Scale Control is set to AUTO. |

To display a plot

- In the Sweep Measurement menu, press <3>.

The sweep measurement is performed and the results are plotted and/or printed. See Section 8.3.3, "Performing a Sweep Measurement" for more information.

To save the plot setup as the system default

- In the Sweep Measurement menu, press <4>.
The plot setup parameters, except Start/Stop Frequencies and Drive Level, are saved as the system defaults.

8.3.5 Performing File Maintenance

From the Quick Measure menu, you can perform simple file maintenance on the current log file and current setup file. These functions are available elsewhere in the system, but are provided here as a convenience.

To view the current log file

1. In the Quick Measurement menu, press <7> to choose FILE MAINTENANCE.
2. Press <1> to choose VIEW LOG FILE. When you are finished, press <ESC>.

To print the current log file

- In the Quick Measure File Maintenance menu, press <2>.

To create a log file or change the name

1. In the Quick Measure File Maintenance menu, press <3>.
2. Enter the name of the log file to create or press * (asterisk) to pick from a list of log files.

To delete a log file

1. In the Quick Measure File Maintenance menu, press <4>.
2. Use the arrow keys to choose the log file to delete.
3. Press <ENTER> to confirm, or press <ESC> to abort the procedure. This last step avoids accidentally deleting the log file.

WARNING Once the log file is deleted, it can not be recovered!

To load a setup

1. In the Quick Measure File Maintenance menu, press <5>.
2. Type in the name of the Test Setup.

To load a Test Setup from a list, press * (asterisk) and then <ENTER>. Use the Up- and Down-Arrow Keys to select from the list.

3. Press <ENTER>.

WARNING Trying to load a CNA300 Setup for a CNA 200 may present problems.

To save a setup

- In the Quick Measure File Maintenance menu, press <6>.

All changes are saved to the current Test Setup.

To create a setup

1. In the Quick Measure File Maintenance menu, press <7>.
2. Type in the name of the Test Setup to create.

To see a list of Test Setups currently defined, press * (asterisk) and then <ENTER>.

NOTE The name must be unique. Otherwise, the system will ask if you want to load it or save (overwrite) it. If you choose to load it, any changes you made are lost!

3. Press <ENTER>.

To delete a setup

1. In the Quick Measure File Maintenance menu, press <8>.
2. Use the Up- and Down-Arrow Keys to highlight the Test Setup to delete and press <ENTER>.
3. If you are sure that you selected the Test Setup to delete, press <ENTER>. Otherwise, press <ESCAPE> to abort the delete command.

WARNING Once the Test Setup is deleted, there is no way to recover it!

8.3.6 Internal Parameters

From the Quick Measure menu, you can access the Internal Parameters menu. This Internal Parameters menu is almost the same as the one described in Section 8.4, "Modifying Internal Parameters," except that option 7 is Calibrate Instrument (instead of Plating Rate Control Parameters).

8.4 Modifying Internal Parameters

This screen allows you to access all CNA 200 and 300 system parameters.

```
TRANSAT CNA-300 Crystal Measurement System U3.03 13:12:45
< Internal Parameters Menu >
```

```
ENTER SELECTION : [ ■ ]
1. SYSTEM PARAMETERS
2. DIGITAL I/O PARAMETERS
3. EXTERNAL I/O PARAMETERS
4. PFC CARD PARAMETERS
5. CALIBRATION FILE MAINTENANCE
6. FILE PATH MAINTENANCE
7. PLATING RATE CONTROL PARAMETERS
8. ALTERNATIVE SPURIOUS SEARCH
```

Figure 8.17 Internal Parameters Menu (CNA 300)

```

TRANSAT CNA-200 Crystal Measurement System U3.03 13:15:05
< Internal Parameters Menu >

```

```

ENTER SELECTION : [ █ ]
1. SYSTEM PARAMETERS
2. DIGITAL I/O PARAMETERS
3. EXTERNAL I/O PARAMETERS
4. CALIBRATION FILE MAINTENANCE
5. FILE PATH MAINTENANCE
6. ALTERNATIVE SPURIOUS SEARCH

```

Figure 8.18 Internal Parameters Menu (CNA 200)

WARNING Do NOT modify these parameters without consulting the factory. Modifying these incorrectly causes the system to no longer function! The following information has been provided for completeness.

The Internal Parameters menu illustrated is briefly described in the following table.

| Option | Description |
|---------------------------------|---|
| System Parameters | System, Calibration, and Password parameters. |
| Digital I/O Parameters | DOS, View, and Export command strings, and I/O addresses. |
| External I/O Parameters | Parameters that interface to external devices. |
| FFC Card Parameters | Parameters that directly affect the FFC card (CNA 300 only). |
| Calibration File Maintenance | Parameters that allow you to store Calibration files for different fixtures in different directories. |
| File Path Maintenance | Directories that the system uses to create files. |
| Plating Rate Control Parameters | Parameters that interface with an external plating machine (CNA 300 only). |
| Alternative Spurious Search | Parameters that directly affect both the Spurious Search and the Secondary Spurious Search. |

8.4.1 System Parameters Screen

This screen allows you to change System, Calibration, and Password parameters.

TRANSAT CNA-300 Crystal Measurement System U3.03 13:16:02

```

=====I SYSTEM PARAMETERS I=====
Test Mode      : MANUAL
Consecutive Errors : 100
Frequency Dist Factor : 0.33

-----Reference Parameters-----
Short Inductance : 6.000 nH
Res Inductance   : 6.000 nH
2nd PI Capacitance : 0.170 pF
Lead Inductance  : 0.000 nH
Short Resistance : 0.000 Ω
PI Capacitance   : 2.350 pF
Ref Resistance    : 51.000 Ω
Stray Capacitance : 1.240 pF

-----FREQUENCY FORMATS-----
PPM / KHZ (0/1) : 0

-----Password Parameters-----
Password Enable : 0
Password        : transat
    
```

Press <SPACE> to select, then <RETURN> to confirm or <ESCAPE> to abort

Figure 8.19 System Parameters Screen

The System Parameters are described in the following table.

| Parameter | Description |
|-----------------------|--|
| Test Mode | <p>The mode the system will operate in.</p> <p>MANUAL: The operator must load the crystal into the PI Network and then press <SPACEBAR> to cause a measurement to be performed.</p> <p>AUTOMATIC: Automatically detects when a part is installed in the PI Network. If a part is not properly inserted in the PI Network, a bad measurement may occur. Drive level testing should not be enabled in this mode.</p> <p>EXTERNAL: Allows the measurement to be triggered externally from other equipment (see the CNA Application Notes).</p> <p>CONTINUOUS: Performs a continuous measurement. If a part is not properly inserted in the PI Network, a bad measurement may occur. Nevertheless, the measurement still occurs until the user presses ESC.</p> <p>TEST WHEEL: Not currently supported.</p> |
| Frequency Dist Factor | <p>This determines how the pcs will be divided in the Test screen (See Section 5.4). For example if the Frequency Dist Factor parameter is 0.33, then the "pcs" heading in the Test Screen will display the number of parts that passed that are within 1/3 of the nominal, between 1/3 and 2/3 of the nominal, and beyond 2/3 of the nominal (but still passing). Where nominal is the midpoint of the range (from Min to Max) that was specified in the Fs or FL1 test.</p> |
| Consecutive Errors | <p>If N consecutive tests fail, the system will leave Measurement mode. N is the value you entered in the Consecutive Errors parameter.</p> |

| Parameter | Description |
|--------------------|---|
| Short Inductance | The inductance of the reference short used for calibration. Valid values are between 0 and 999 nH. |
| Short Resistance | The reference resistance used for the calibration. For a short, this value should be 0. Valid values are between 0 and 999 ohms. |
| Res Inductance | The inductance of the reference resistance used for calibration. Valid values are between 0 and 999 nH. |
| PI Capacitance | The characteristic capacitance value of the PI Network. This value is usually defined by design and will not vary significantly from PI network to PI network of the same model type. This value has been placed on the bottom of the PI Network as CP1. Valid values are between 0 and 9.8 pF. |
| 2nd PI Capacitance | The secondary PI capacitance that describes the PI network. This value has been placed on the bottom of the PI Network as CP2. Valid values are between 0 and 9.8 pF. |
| Ref Resistance | The resistance for the reference resistor used for the calibration. Valid values are between 0 and 999 ohms. |
| Lead Inductance | Allows the system to compensate for the inductance of the crystal leads. Currently not used. Should be set to 0. |
| Stray Capacitance | The capacitance of the CL insert socket. This value has been placed on the bottom of the PI Network as CS. Valid values are between 0 and 9.8 pF. |
| PPM / KHz (0/1) | Frequency specification limits can be in either ppm or KHz of the Target frequency. 0 indicates ppm, and 1 indicates KHz. This affects the specifications in the Fs and FL tests. |
| Password Enable | Enable/disable password protection on the Setup Model and Configure System options of the Main menu. Enter 0 to disable, 1 to enable. |
| Password | The system password when the Password Enable parameter is set to 1. The password can be up to 8 ASCII characters. You will be prompted for a password when you select Setup Model or Configure System from the Main menu. |

8.4.2 Digital I/O Parameters Screen

The Digital I/O Parameters screen allows you to change DOS, View, and Export command string, and I/O addresses.

```

TRANSTAT CNA-300 Crystal Measurement System U3.03 14:28:09
-----[ Digital I/O Parameters ]-----
Output Port Address : 0x280
Relay Enable       : 0x000
Counter Address    : 0x000
CL Insert Enable   : 0x000

DOS Command String : swap -D -F -Q command
VIEW Command String : swap -D -F -Q command /c browse
EXPORT Command String : swap -D -F -Q command /c

MCT\CNA Mode (0=MCT) : 1
CNA System Type      : CNA-300
MCT Direct Drive Enable : 0
MCT PIO-24 Base Address : 0x220
CNA PIO24/PPIO-DIO24H : PIO-24
CNA PIO-24 Base Address : 0x220

Transmission/Reflection : 0
  
```

Press <SPACE> to toggle value ON (1) or OFF (0)

Figure 8.20 Digital I/O Parameters Screen

The Digital I/O Parameters screen illustrated is described in the following table.

| Parameter | Description |
|-------------------------|---|
| Output Port Address | The I/O address of the output port used for communicating with an external relay rack. |
| Relay Enable | The byte value used to toggle the Relay Enable Signal. |
| Counter Address | The I/O address of the counter chip. |
| CL Insert Enable | The byte value used to toggle the CL Insert Enable Signal. |
| DOS Command String | The character string to invoke the DOS Command Prompt. |
| VIEW Command String | The character string to invoke the data viewer. |
| EXPORT Command String | The character string to export data to dBASE format. |
| MCT\CNA Mode | Set to 0 for Transat MCT or 1 for Transat CNA. |
| CNA System Type | Set to a CNA 200 or a CNA 300. |
| MCT Direct Drive Enable | Set to 1 to enable, or 0 to disable. |
| MCT PIO-24 Base Address | The base address of the PIO-24 card used for Transat MCT. |
| CNA PIO24/PPIO-DIO24H | Sets the interface type used to communicate with the CNA. Currently there are three types: PIO-24, PPIO-24, and DIRECT. |
| CNA PIO-24 Base Address | The base address of the interface card used for the Transat CNA. |
| Transmission/Reflection | Set to 0 for transmission method, or 1 for reflection method. |

8.4.3 External I/O Parameters Screen

The External I/O Parameters screen allows you to change parameters that interface to an external device.

FRANSAT CNA-300 Crystal Measurement System U3.03 14:34:06

```

===== [ External I/O Parameters ] =====
Pre-Measurement Delay      : 1          msecs
Enable External I/O CTRL   : 0
I/O PIO-24 Base Address    : 0x280
Test Start (in) mask      : 0x001      data : 0x001
Test Stop (in) mask       : 0x002      data : 0x002
Pass Fail 1 (out) mask    : 0x001      data : 0x001
Pass Fail Frequency (out) mask : 0x002      data : 0x002
Pass Fail Resistance (out) mask : 0x004      data : 0x004
Test Complete (out) mask  : 0x008      data : 0x008
Test Complete Pulse Width : 0          msecs
  
```

Enter the new value, then <ENTER> to confirm or <ESCAPE> to abort

Figure 8.21 External I/O Parameters Screen

The External I/O Parameters screen illustrated is described in the following table.

| Parameter | Description |
|----------------------------|--|
| Pre-Measurement Delay | The amount of time to delay after getting Test Start signal before making a measurement. Specified in milliseconds. |
| Enable External I/O CTRL | Set to 1 to enable external I/O control. |
| I/O PIO-24 Base Address | The base address for the PIO-24 card used for external I/O. |
| Test Start (in) | This signal starts the measurement for the current crystal. Address mask and data for monitoring the Test Start I/O line. Both are displayed in hexadecimal format. The defaults for the mask and the data are (0x001). |
| Test Stop (in) | This aborts the current test. Address mask and data for monitoring the Test Stop I/O line. Both are displayed in hexadecimal format. The defaults for the mask and the data are (0x002) and (0x000), respectively. |
| Pass Fail 1 (out) | This Address mask and data for outputting the Pass Fail 1 I/O line. Both are displayed in hexadecimal format. The defaults for the mask and the data are (0x001) and (0x000), respectively. Outputs the value in the data parameter when the current part passes it's specification, otherwise the data value is inverted. This is set before the Test Complete pulse. |
| Pass Fail Frequency (out) | Address mask and data for outputting a successful Frequency or all three Load Frequency tests. Both are displayed in hexadecimal format. The defaults for the mask and the data are both (0x002). The Pass Fail Frequency pulse is performed after the part is measured and the either the Frequency fails or any of the Load Frequencies fail. |
| Pass Fail Resistance (out) | Address mask and data for a successful Resistance. Both are displayed in hexadecimal format. The defaults for the mask and the data are both (0x004). The Pass Fail Resistance pulse is performed after the part is measured and the Resistance fails. |

| Parameter | Description |
|---------------------------|---|
| Test Complete | Address mask and data for outputting Test Complete. Both are displayed in hexadecimal format (0x??). The Test Complete pulse is performed after the part is measured and the Pass Fail 1 signal is set. |
| Test Complete Pulse Width | The pulse width for the Test Complete I/O line specified in milliseconds. |

8.4.4 FFC Card Parameters Screen (CNA 300 Only)

The FFC Card Parameters screen allows you to change parameters that directly affect the Transat FFC card.

TRANSAT CNA-300 Crystal Measurement System U3-03 13:22:37

```

┌ FFC Card Parameters ─┐
Enabled      : 1
Base Address : 0x300 (hex)
Internal Reference : 0

```

Press <SPACE> to select, then <RETURN> to confirm or <ESCAPE> to abort

Figure 8.22 FFC Card Parameters Screen (CNA 300)


The FFC Card Parameters screen illustrated is described in the following table.

| Parameter | Description |
|--------------------|--|
| Enabled | Set to 1 if a TRANSAT Fast Frequency Card is used for frequency measurement. |
| Base Address | The I/O address of the FFC. |
| Internal Reference | Either enabled (1) or disabled (0) |

8.4.5 Calibration File Maintenance Screen

The Calibration File Maintenance screen allows you to use multiple fixtures (i.e. Pi Networks) easily by allowing you to place calibration files for the different fixtures in different directories.

TRANSAT CNA-300 Crystal Measurement System V3.03 13:24:06



Enter a selection from the menu

Figure 8.23 Calibration File Maintenance Screen

The Calibration File Maintenance screen illustrated is described in the following table.

| Option | Description |
|---------------|---|
| 1. Load | Loads the selected Calibration file. |
| 2. Save | Saves any changes made to the currently selected Calibration file. |
| 3. Create ... | Creates a calibration file. A newly created Calibration file will contain the contents of currently loaded Calibration file. The newly created Calibration file will become the default Calibration file. |
| 4. Delete ... | Deletes the calibration file. |

8.4.6 Parameter File Paths Screen

This screen allows you to specify the directories that will contain the files the system creates.

| [Parameter File Paths] | |
|---------------------------|---|
| SYSTEM FILE PATH | : |
| LOG FILE PATH | : |
| CALIBRATION FILE PATH | : |
| SCRIPT FILE PATH | : |
| EXTERNAL REPORT FILE PATH | : |

Figure 8.24 Parameter File Paths Screen

The Parameter File Paths screen illustrated is described in the following table.

| Parameter | Description |
|---------------------------|--|
| System File Path | Directory that contains the measurement system programs. |
| Log File Path | Directory that the Log files are stored in. |
| Calibration File Path | Directory the Calibration file is stored in. This parameter and the Calibration File Path parameter (in the Calibration File Maintenance screen) contain the same information. |
| Script File Path | Directory where your customized reports are stored. |
| External Report File Path | Directory where the DBF files you generated from your batch files are stored. |

If the path is blank (empty), then the files are stored in the current directory. Normally, this is at C:\TESTMEAS.

8.4.7 Plating Rate Control Setup Parameters Screen (CNA 300 Only)

This screen allows you to change parameters that interface with an external plating machine.


| Plating Rate Control Setup Parameters | | | |
|---|------------|----------------------------------|-------------|
| Plating Rate Control Enable : <input checked="" type="checkbox"/> | | | |
| I/O Card Address : 0x0240 (hex) | | | |
| | BIT MASK | UVALUE | DELAY (Sec) |
| External Enable | : 0x01 | 0x00 | 0.0 |
| External Start | : 0x02 | 0x00 | |
| External Stop | : 0x04 | 0x00 | |
| Done Flag <OUTPUT> | : 0x80 | | 0.5 |
| FILAMENT CTRL (ALL) | : 0x01 | | |
| SHUTTER <OUTPUT> | : 0x08 | 0x00 | |
| | BIT MASK | PLATING TIME (Sec) | |
| Plating Time Out | : 0x04 | 20.00 | |
| Defective Crystal | : 0x02 | | |
| Control Pulse Width | : 100 msec | <for Defective Xtal or Time Out> | |

Figure 8.25 Plating Rate Control Parameters Screen (CNA 300)

NOTE When the *Plating Rate Control Enable* parameter is enabled (set to 1), the Main menu will contain two more options, Plate and Plate Setup.

The Plating Rate Control Setup Parameters screen illustrated is described in the following table.

| Parameter | Description |
|-----------------------------|--|
| Plating Rate Control Enable | Set to 1 to enable plating control, 0 to disable. |
| I/O Card Address | The base address of the I/O card used to communicate with the plating system. |
| External Enable (in) | The Bit Mask, Value, and Delay (in ms) used to enable plating from an external signal. The Bit Mask and Value are displayed in hexadecimal format (0x??). |
| External Start (in) | This signal allows remote operation of plating from an external source. The Bit Mask and Value used to start plating from an external signal. The Bit Mask and Value are displayed in hexadecimal format (0x??). |
| External Stop (in) | The Bit Mask and Value used to stop plating from an external signal. The Bit Mask and Value are displayed in hexadecimal format (0x??). |
| Done Flag (OUTPUT) | The Bit Mask used to signal that plating is done (TRUE). The Delay specifies how long the Done Flag is present (in milliseconds). This forms a logic low-high-low pulse. |
| FILAMENT CTRL (ALL) | The Bit Mask used to define the I/O line used for controlling a filament SSR during plating. |
| SHUTTER (OUTPUT) | The Bit Mask and Value used to close the shutter. The Bit Mask and Value are displayed in hexadecimal format (0x??). |
| Plating Time Out | The amount of time (in seconds) allowed for a crystal to plated to the desired frequency. The Bit Mask is displayed in hexadecimal format (0x??). |
| Defective Crystal | The Bit Mask used to indicate the system is unable to lock to the crystal. |
| Control Pulse Width | The amount of time (in msec) the pulse will be held for the defective crystal or plating time out signal. |



8.4.8 Alternative Spurious Search

TRANSAT CNA-300 Crystal Measurement System V3.03

11:10:22

| [SPURIOUS SEARCH PARAMETERS] | | |
|--------------------------------|------------------------|---------|
| Secondary Sweep Enable | <1=ON> | : 1 |
| Spurious Sensitivity | <from -45 to -1 db> | : -25.0 |
| Per point dwell time | <from 0 to 20000 usec> | : 500 |
| Spurious search points | <100 to 500 pts> | : 500 |
| Secondary Sweep Points | <10 to 200 pts> | : 50 |
| Secondary Sweep Bandwidth | <1 to 500 ppm > | : 100 |

Press <SPACE> to toggle value ON (1) or OFF (0)

Figure 8.26 Alternative Spurious Search

This screen allows you to change the parameters described in the following table.

| Parameter | Description |
|---------------------------|--|
| Secondary Sweep Enable | When set to 1, this enables a secondary sweep of every spurious response to better identify it's resistance. |
| Spurious Sensitivity | The sensitivity of the system for detecting spurious responses. Valid values are between -45 and -1 dB. |
| Per point dwell time | The amount of time to dwell per point before measuring it's impedance during a Spurious Test. This is specified in microseconds. Valid values are between 0 and 20000 uS. |
| Spurious search points | The number of points to measure over the spurious search region. The higher the number, the finer the resolution of spurious modes. Valid values are between 100 and 500 points. |
| Secondary Sweep Points | The number of points to sweep for each secondary sweep. Valid values are between 10 and 200 points. |
| Secondary Sweep Bandwidth | The bandwidth of each secondary sweep. Valid values are between 1 and 500 khz or ppm. |

APPENDIX A MEASUREMENT TYPES

The CNA 300 is a unique instrument in that it offers the ability to perform PHASE LOCKED measurements and FREQUENCY LOCKED impedance and admittance measurements. This capability allows the instrument much flexibility in making measurements.

A PHASE LOCKED measurement is made when the CNA 300 uses an analog phase lock circuit to 'lock on' to the crystal resonance. The advantage to this method is very fast acquisition of the crystal frequency. The disadvantage of this method is that phase locking might be impractical under certain conditions. For example, the crystal response may be weak due to low drive level, or the device has a high Q response.

To overcome the problem of low drive level measurement, a CNA FREQUENCY LOCKED measurement can effectively extend the range of the instrument to less than 10 nW for most devices. Note that the FREQUENCY LOCKED measurement is also valid at higher drive levels, but tends to be slower than the PHASE LOCKED methods.

To overcome the problem with high Q devices in a PHASE LOCKED measurement, the CNA incorporates a special 'HIGH Q' mode that slows the basic analog frequency sweep rate to allow the instrument to phase lock to higher Q devices (devices with $Q > 500000$).

There are a number of measurements available with the CNA test system. Some of the measurements are available for crystal measurements while others are only available from the QUICK MEASUREMENT screen for engineering analysis. The following are descriptions of the different measurements available:

A.1 Frequency (CNA 300 Only)

Frequency measurements of the crystals will be performed at the phase angle set in the Measurement Angle parameter (in the Direct Lock Measurement Parameters screen).

A.2 Freq & Resist (CNA 300 Only)

Frequency, resistance, and drive power measurements of the crystals will be performed at the phase angle set in the Measurement Angle parameter (in the Direct-Lock Measurement Parameters screen).




Figure A.1 Direct Lock Measurement Parameters Screen

The following table describes the parameters found in the Direct Lock Measurement Parameters screen.

| Parameter | Description |
|-------------------------|---|
| Measurement Angle (deg) | The angle that the measurements will be performed at. |
| Search Bandwidth (ppm) | The distance to search centered around the main resonance (Target frequency). This is specified in ppm of the main resonance. |
| High Q Enable | Used for measuring high Q crystals (Q greater than 500K). A value of 1 enables slow sweep, 0 disables it. |

| Parameter | Description |
|--------------------------|--|
| Automatic Gate | If set to 1, the system determines the appropriate gate time based on the value entered for Settling Time. Automatic Gate should normally be set to 1 to ensure accurate measurements in the least amount of time. If set to 0, the Counter Gate Time parameter is used. |
| Averaging Number | The number of frequency measurements that will be made at each point. Valid values are between 0 and 30. |
| Delay (msec) | The amount of time needed for the crystal to begin oscillating. A typical value to use is 10 ms. |
| Counter Gate Time (msec) | The amount of time the system uses to count the number of oscillations of the crystal. The number of oscillations is used to determine the frequency of the crystal. For maximum accuracy, set the gate time to 1000 msec (1 sec). |

This measurement is sometimes called a Direct Lock measurement because the frequency and resistance reported are the direct result of locking at the specified phase angle.

A.3 Standard Par (CNA 300 Only)

This method makes a 3-point calculation of the crystal's parameters based on an initial Co measurement and two additional measurements. The measurement is basically performed as follows:

- A Co measurement is made off-resonance.
- A phase-lock measurement is made at the phase angle specified in the Initial Angle parameter (in the Standard Crystal Measurement Parameters screen).
- The admittance and impedance of the crystal at that angle is calculated.
- Using the Co measurement and the first phase locked measurement, calculate the series resonant phase angle and phase lock to the crystal at this angle.
- Measure the admittance and impedance of the crystal at the angle calculated from the previous step.
- Using all three measurements, calculate the crystal motional parameters.

```

===== [ STANDARD CRYSTAL MEASUREMENT PARAMETERS ] =====
Automatic Phase   : 17
Phase Step Angle  : 5.00 deg
Search Bandwidth  : 3000 ppm
High Q Enable     : 0
Automatic Gate    : 0
Averaging Number  : 3
Settling Time     : 5 msec
Initial Angle     : 70.00 deg
Counter Gate Time : 100 msec
< Press END to accept all parameters or ESC to abort >
    
```

Figure A.2 Standard Crystal Measurement Parameters Screen

The following table describes the parameters found in the Standard Crystal Measurement Parameters screen.

| Parameter | Description |
|------------------------|--|
| Automatic Phase | If set to 1, the initial phase angle is automatically reduced based on the frequency of the device. If the frequency is less than 20 MHz, the phase angle is set to 20 degrees. If the frequency is between 20 and 70 MHz, the phase angle is set to 45 degrees. If the frequency is greater than 70 MHz, the value specified in Initial Angle is used. If set to 0, the value specified in Initial Angle is used for all frequencies. |
| Phase Step Angle (deg) | The amount of angle to incrementally increase the Initial Angle, should the system be unable to achieve phase lock with the current angle. |
| Search Bandwidth (ppm) | The distance to search centered around the main resonance (Target frequency). This is specified in ppm of the main resonance. |
| High Q Enable | Used for measuring high Q crystals (Q greater than 500K). Setting to 1 enables slow sweep, 0 disables it. |
| Automatic Gate | If set to 1, the system determines the appropriate gate time based on the value entered for Settling Time. Automatic Gate should normally be set to 1 to ensure accurate measurements in the least amount of time. If set to 0, the Counter Gate Time parameter is used. |
| Averaging Number | The number of frequency measurements that will be made at each point. Valid values are between 0 and 30. |
| Delay | Specifies the amount of time the system waits at each point while sweeping the part. A typical value is 10 ms. |
| Initial Angle (deg) | The first phase angle the system will try when attempting to phase lock to the crystal. |
| Counter Gate Time | The amount of time the system uses to count the number of oscillations of the crystal. For maximum accuracy, set the gate time to 1000 msec (1 sec). |

A.4 Special Par (CNA 300 Only)

Measures the crystal motional parameters using a multiple point admittance circle fit. Full motional parameters are derived as well as off resonance C_o . Again the measurement points are derived using phase locked measurements. Additionally, the phase angles for measurements within the 3 dB bandwidth of the device are used. This generally allows more stable and repeatable measurements. The measurement sequence is:

- A C_o measurement is made off-resonance
- A phase-lock measurement is made at the phase angle specified in the Initial Angle parameter .
- The admittance and impedance of the crystal at that angle is calculated.
- Using the C_o measurement and the first phase locked measurement, calculate the series resonant phase angle.
- A series of phase-locked measurements are made within ± 3 dB (decibels) from the calculated series resonant phase angle of the crystal. The Points on Circle parameter specifies how many of these measurements will be made. Again, the admittance and impedance of the crystal are measured at these angles.
- Using these measurements, calculate the motional parameters of the crystal by fitting this measurement data to a circle.

NOTE The 3 dB phase angles are used to insure that the measurement points appear on the 'right hand side' of the admittance circle of the device.

```

┌ SPECIAL CRYSTAL MEASUREMENT PARAMETERS ┐
Automatic Phase   : 1
Phase Step Angle : 5.00 deg
Points On Circle  : 3
Search Bandwidth : 3000 ppm
High Q Enable     : 0
Automatic Gate    : 0
Averaging Number : 3
Settling Time    : 5 msec
Initial Angle     : 70.00 deg
Counter Gate Time : 100 msec
└───────────────────────────────────────────┘
< Press END to accept all parameters or ESC to abort >

```

Figure A.3 Special Crystal Measurement Parameters Screen

The following table describes the parameters found in the Special Crystal Measurement Parameters screen.

| Parameter | Description |
|------------------------|--|
| Automatic Phase | If set to 1, the initial phase angle is automatically reduced based on the frequency of the device. If the frequency is less than 20 MHz, the phase angle is set to 20 degrees. If the frequency is between 20 and 70 MHz, the phase angle is set to 45 degrees. If the frequency is greater than 70 MHz, the value specified in Initial Angle is used. If set to 0, the value specified in Initial Angle is used. |
| Phase Step Angle (deg) | The amount of angle to incrementally increase the Initial Angle, should the system be unable to achieve phase lock with the current angle. |
| Points On Circle | The number of points to measure on the admittance circle. Valid values are between 3 and 20. |
| Search Bandwidth (ppm) | The distance to search centered around the main resonance (Target frequency). This is specified in ppm of the main resonance. |
| High Q Enable | Used for measuring high Q crystals (Q greater than 500K). Setting to 1 enables slow sweep, 0 disables it. |
| Automatic Gate | If set to 1, the system determines the appropriate gate time based on the value entered for Settling Time. Automatic Gate should normally be set to 1 to ensure accurate measurements in the least amount of time. If set to 0, the Counter Gate Time parameter is used. |
| Averaging Number | The number of frequency measurements that will be made at each point. Valid values are between 0 and 30. |
| Delay | Specifies the amount of time the system waits at each point while sweeping the part. A typical value is 10 ms. |
| Initial Angle (deg) | The first phase angle the system will try when attempting to phase lock to the crystal. |
| Counter Gate Time | The amount of time the system uses to count the number of oscillations of the crystal. For maximum accuracy, set the gate time to 1000 msec (1 sec). |

A.5 Multi Point (CNA 300 Only)

The multiple-point measurement is similar to the Special Parameter measurement except the phase angles of the measurement points are not derived based on the 3 dB phase angles of the crystal. The key parameters are the Initial Angle, Points On Circle and Phase Sweep Range. The measurement sequence is:

- A Co measurement is made off-resonance
- A phase-lock measurement is made at the phase angle specified in the Initial Angle parameter .

- The admittance and impedance of the crystal at that angle is calculated.
- Make additional phase locked measurements by stepping the phase angle of each measurement based on:

$$\text{Phase Step} = \text{Phase Sweep Range} / (\text{Points On Circle} - 1)$$

Repeat until the number of measurements specified by the Points On Circle parameter have been made.

- Using these measurements, calculate the motional parameters of the crystal by fitting the measurement data to an admittance circle.




Figure A.4 Multi-Point Measurement Parameters Screen

The following table describes the parameters found in the Multi-Point Measurement Parameters screen.

| Parameter | Description |
|-------------------------|--|
| Automatic Phase | If set to 1, the initial phase angle is automatically reduced based on the frequency of the device. If the frequency is less than 20 MHz, the phase angle is set to 20 degrees. If the frequency is between 20 and 70 MHz, the phase angle is set to 45 degrees. If the frequency is greater than 70 MHz, the value specified in Initial Angle is used. If set to 0, the value specified in Initial Angle is used. |
| Phase Step Angle (deg) | The amount of angle to incrementally increase the Initial Angle, should the system be unable to achieve phase lock with the current angle. |
| Points On Circle | The number of points to measure on the admittance circle. Valid values are between 3 and 20. |
| Search Bandwidth (ppm) | The distance to search centered around the main resonance (Target frequency). This is specified in ppm of the main resonance. |
| High Q Enable | Used for measuring high Q crystals (Q greater than 500K). Setting to 1 enables slow sweep, 0 disables it. |
| Automatic Gate | If set to 1, the system determines the appropriate gate time based on the value entered for Settling Time. Automatic Gate should normally be set to 1 to ensure accurate measurements in the least amount of time. If set to 0, the Counter Gate Time parameter is used. |
| Averaging Number | The number of frequency measurements that will be made at each point. Valid values are between 0 and 30. |
| Delay | Specifies the amount of time the system waits at each point while sweeping the part. A typical value is 10 ms. |
| Initial Angle (deg) | The first phase angle the system will try when attempting to phase lock to the crystal. |
| Phase Sweep Range (deg) | The total amount of phase to sweep (see the measurement sequence discussion above). Valid values are between 0.0 and 99.9 degrees. A good choice would be 45.0 degrees. |

| Parameter | Description |
|-------------------|--|
| Counter Gate Time | The amount of time the system uses to count the number of oscillations of the crystal. For maximum accuracy, set the gate time to 1000 msec (1 sec). |

A.6 Sweep Measurement

The parameters of the crystal are measured by sweeping a span of frequencies around the Target Frequency. The Target Frequency is specified in the Fs or FL1 test. The span is specified by the Sweep Span parameter in the Sweep Crystal Measurement Parameters screen. This measurement has the advantage of not needing to achieve phase lock at any time. The basic measurement sequence is to:

- Rapidly sweep a bandwidth on either side of the target frequency to identify the main resonance.
- Repeatedly decrease the bandwidth of the sweep until the measurement is within the 3 dB bandwidth of the crystal.
- Once sufficient points within the 3 dB bandwidth of the part are measured, calculate the motional parameters of the crystal from the admittance circle fit.

NOTE As the bandwidth of the sweep is reduced, the measurement time is increased to allow for device settling.




Figure A.5 Sweep Crystal Measurement Parameters Screen

The following table describes the parameters found in the Sweep Crystal Measurement Parameters screen.

| Parameter | Description |
|------------------------|--|
| Search Bandwidth (ppm) | The distance to sweep centered around the main resonance (Target frequency). This is specified in ppm of the main resonance. |
| High Q Enable | Used for measuring high Q crystals (Q greater than 500K). A value of 1 enables slow sweep, 0 disables it. |
| Delay (msec) | Settling Time is the amount of time the system waits at each point while sweeping the part. A typical value to use is 10 ms. |

A.7 Phase Locked Impedance

Phase Locked Impedance measures the impedance and admittance at the specified phase angle set by the INITIAL ANGLE parameter on the Measurement Parameters Screen. This measurement is only available at the Quick Measurement screen.

A.8 Frequency Set Impedance

Frequency Locked Impedance measures the impedance and admittance at the specified Target Frequency. This measurement is only available at the Quick Measurement screen.

A.9 Insert Capacitance

Measures the capacitance of the physical capacitor inserted in the Pi-network. Please note that this measurement changes the value of the insert capacitance displayed on the Quick Measurement screen test setup.

A.10 Spurious Search

Searches for spurious modes of oscillation. Only the first six responses within the spurious search band are reported. The Spurious Search measurement is used in conjunction with another parameter measurement.

A.11 DL Test or DLD Sweep

Measures the changes in frequency and resistance as the drive is swept from the value specified by *Low Drive* to the value specified by *Drive Level*. The results are displayed on the screen.

The *Low Drive* limit depends on the actual R and Q of the crystal.

When performing a DLD Sweep from the Quick Measure screen, the crystal to be measured should not be placed in the Pi until prompted by a message on the screen. This will ensure the crystal has not been hit with high drive before executing the DL test.




Figure A.6 DLD Sweep Measurement Parameters Screen

The following table describes the parameters found in the DLD Sweep Measurement Parameters screen.

| Parameter | Description |
|---|---|
| Max Delta R (%) | Maximum allowable change in resistance. |
| Max Delta F (ppm) | Maximum allowable change in frequency. |
| Low Drive (uW) | The low-drive level. |
| <p>NOTE The high-drive level is the Drive Power parameter that was set in the Basic Test screen.</p> | |
| Number of Pts | The number of measurements that will be made (0 to 100 points). |
| Delay (mSec) | The amount of time the crystal needs to settle before each measurement. |

A.12 Calculate CL

Calculates the effective load capacitance in the system based on measuring a reference crystal.

APPENDIX B LOAD CAPACITANCE MEASUREMENTS

The CNA supports three methods of measuring the load capacitance characteristics of a crystal:

- Numerical Calculation of Load Frequency (NUMERICAL).
- Load Frequency Measurement with a Physical Load Capacitance (PHYSICAL).
- Load Frequency Measurement Using Equivalent Reactance (EQREACT).

B.1 Numerical

This method calculates the load capacitance without a CL insert capacitor being placed in the PI Network.

Advantage: This method is adequate for overtone crystals.

Disadvantage: Accuracy problems could occur in fundamental crystals with a load capacitance smaller than 20 pF.

To use the Numerical method

1. Set the Load CL Mode parameter in the Load Capacitance Measurement Parameters window (See Section 6.4) to NUMERICAL.
2. Set the Insert Cap parameter in the Load Capacitance Measurement Parameters window (See Section 6.4) to 0 (zero). This indicates that there is no insert capacitor.
3. Set the Target Cap parameter (in the FL1, FL2, or FL3 Test window) to the desired target load capacitance.

B.2 Physical

This method uses a load capacitance (capacitor placed in the PI Network) close the desired load capacitance. This will cause the crystal to operate close to, or at, the desired load capacitance.

Advantage: Variations from device to device are eliminated by a crystal parameter measurement of each part.

Disadvantage: A limited number of CL inserts are used to cover the entire range of target load capacitance values. This can be a problem for automation applications where the load capacitor cannot be easily changed.

To use the Physical method

1. Set the Load CL Mode parameter (in the Load Capacitance Measurement Parameters window) to PHYSICAL.
2. Set the Insert Cap parameter (in the Load Capacitance Measurement Parameters window) to the value of the capacitor placed in the PI Network.
3. Set the Target Cap parameter (in the FL1, FL2, or FL3 Test window) to the desired target load capacitance.
4. When testing begins, the operator will be prompted to insert a short circuit in the PI Network to allow measurement of the load capacitance. (The short circuit is to be placed in the Pi Network; not the load insert socket!)
5. Press any key (except <ESC>) to measure the load capacitor. After measuring the load capacitance, the user is put into the Test Screen. Remove the short circuit from the Pi Network and begin testing.

B.3 EQREACT

This method measures a target load frequency exactly at the equivalent negative reactance of the desired load capacitance. This measurement is performed without a load capacitor in the PI Network.

Advantage: Easy to setup.

Disadvantage: Accuracy problems could occur with low power measurements.

To use the Egreact method

1. Set the Load CL Mode parameter (in the Load Capacitance Measurement Parameters window) to EQREACT.
2. Set the Insert Cap parameter (in the Load Capacitance Measurement Parameters window) to 0 (zero). This indicates that there is no insert capacitor.
3. Set the Target Cap parameter (in the FL1, FL2, or FL3 Test window) to the desired target load capacitance.

A Target Capacitance value which takes into consideration capacitances inherent to the Pi Network can be determined by measuring a reference crystal. This measurement is enabled from the Lot Description screen at the beginning of a test. (See Section B.4)

The accuracy of this method is close to that of the Physical method without the need for an actual load capacitance.

The measurement is accomplished by examining the reactance slope of the crystal at the frequency of interest, and calculating the load frequency that matches the appropriate equivalent reactance.

B.4 Measure Reference Crystal

The system can determine the Target Load Capacitance value based on measuring a reference crystal with a known frequency, at a known load capacitance, at the start of a test. This measurement is available when a FL1, FL2, and/or FL3 test is enabled and EQREACT Load Capacitance Measurement method is selected.

To measure a reference crystal

1. From the Lot Description Screen (See Section 5.2), set the Measure Reference Crystal parameter to 1 and press <END>.

The Reference Crystal Parameters Window is displayed.

```
[ Reference Crystal Parameters ]
Reference Crystal Frequency : 20.000000 (MHz)
Reference Load Capacitance  : 10.00 (pF)
Press [END] to accept changes, [ESCAPE] to ABORT
```

Figure B.1 Reference Crystal Parameters Window

2. Enter the reference crystal frequency and load capacitance and press <ENTER>.

After measuring the reference crystal, the Target Capacitance value is calculated and the Current Test Setup screen is displayed. (See Section 5.3).

APPENDIX C EXPORTING DATABASE DATA

This appendix describes how to export data to DBF (dBASE) files using either of these two methods:

- Using system menus.
- Using batch files.

The data exported was created by the system while tests were being run. When a test is run, a Lot file and Item file are created. It is the information in these two files that is exported to dBASE compatible files.

C.1 Exporting Data Using System Menus

To export using the CNA menus

1. From the Main menu, press <3>. The View Data menu will display.
2. Press <8>.

The system will create a lot information file (.DBL) and an individual measurement file (.DBF) based on the currently selected test data. An index file (.CDX) is also created for the individual measurement file. All three files have the same name as the selected test data.

If the files already exist, you are asked if you want to overwrite them. Press <1> to overwrite, or any other key to abort the process.

C.2 Exporting Data Using Batch Files

An alternative way to move data to .DBF files is by using DOS batch files. Measurement data from multiple test runs can be exported to DBF files by simply typing the name of a batch file.

For example, suppose five test runs with log names of TEST1, TEST2, TEST3, TEST4, and TEST5 are to be exported. You can create a batch file similar to the following (using an ASCII text editor) to export the data.

```
rem This is a batch file to export data to DBF formatted files.
rem Export the lot and item file data to DBF formatted file called
rem TEST1.DBL and TEST1.DBF
dbfcvt -iTEST1 -oTEST1
rem Similarly, export TEST2.
dbfcvt -iTEST2 -oTEST2
rem Similarly, export TEST3.
dbfcvt -iTEST3 -oTEST3
rem Similarly, export TEST4.
dbfcvt -iTEST4 -oTEST4
rem Similarly, export TEST5.
dbfcvt -iTEST5 -oTEST5
```

After running the batch file above, ten new files are created:

TEST1.DBL, TEST1.DBF,
TEST2.DBL, TEST2.DBF,
TEST3.DBL, TEST3.DBF,
TEST4.DBL, TEST4.DBF,
TEST5.DBL, and TEST5.DBF.

C.3 Export Data File Descriptions

This section describes the fields in the Lot and Item files.

The Lot file (DBL) has one record containing setup information for that lot. The format of the file is shown in the following table.

| Name | Type | Length | Decimal | Description |
|----------|--------|--------|---------|--|
| LOTNAME | string | 9 | 0 | Lot Name |
| SYSNAME | string | 9 | 0 | System File Name |
| MCTNAME | string | 9 | 0 | Calibration File Name |
| LOGPATH | string | 44 | 0 | Log File Path |
| SYSPATH | string | 44 | 0 | System File Path |
| MCTPATH | string | 44 | 0 | Calibration File Path |
| RPTFMT | number | 2 | 0 | Report format |
| TARFREQ | number | 11 | 7 | Target Frequency |
| LCAPMODE | number | 2 | 0 | Load Cap Mode |
| LOADFRQ1 | number | 11 | 7 | Load Freq[0] |
| LOADFRQ2 | number | 11 | 7 | Load Freq[1] |
| LOADFRQ3 | number | 11 | 7 | Load Freq[2] |
| TARGCAP1 | number | 11 | 7 | Target Cap[0] (in pF) |
| TARGCAP2 | number | 11 | 7 | Target Cap[1] (in pF) |
| TARGCAP3 | number | 11 | 7 | Target Cap[2] (in pF) |
| CL2REF | number | 2 | 0 | Reference freq for CL2 |
| CL3REF | number | 2 | 0 | Reference freq for CL3 |
| INSRTCAP | number | 11 | 7 | Insert Cap (in pF) |
| DRIVPWER | number | 11 | 7 | Drive Power (in W) |
| ESR | number | 11 | 7 | ESR (in ohms) |
| PLTATMPS | number | 5 | 0 | Plating Attempts |
| TOTPASS | number | 5 | 0 | Total Passed |
| TOTFAIL | number | 5 | 0 | Total failed |
| PPMESERR | number | 5 | 0 | Post Plate Measure Errors |
| PPSPCERR | number | 5 | 0 | Post Plate Spec Errors |
| STARTDTE | string | 12 | 0 | Start Plating Date (DD Mmm YYYY) |
| STARTTME | string | 9 | 0 | Start Plating Time (HH:MM:SS) |
| STOPDTE | string | 12 | 0 | Stop Plating Date (DD Mmm YYYY) |
| STOPTME | string | 9 | 0 | Stop Plating Time (HH:MM:SS) |
| STTIME | number | 12 | 0 | Elapsed time since start of application at start of lot. |
| ENDTIME | number | 12 | 0 | Elapsed time since start of application at end of lot. |
| ELAPTIME | number | 11 | 1 | Elapsed time (in seconds) |
| NOMSEREN | number | 1 | 0 | Enable series frequency specification |
| NOMLOEN1 | number | 1 | 0 | Enable load frequency[0] specification |
| NOMLOEN2 | number | 1 | 0 | Enable load frequency[1] specification |
| NOMLOEN3 | number | 1 | 0 | Enable load frequency[2] specification |

| Name | Type | Length | Decimal | Description |
|-----------|--------|--------|---------|---|
| NOMRESEN | number | 1 | 0 | Enable resistance specification |
| NOML1EN | number | 1 | 0 | Enable L1 specification |
| NOMC1EN | number | 1 | 0 | Enable C1 specification |
| NOMC0EN | number | 1 | 0 | Enable C0 specification |
| NOMC0C1EN | number | 1 | 0 | Enable C0/C1 specification |
| NOMQEN | number | 1 | 0 | Enable Q specification |
| DLTENB | number | 1 | 0 | Enable Drive Level Test |
| DLTMAXR | number | 11 | 7 | Drive Level Test Max Resistance |
| DLTMAXF | number | 11 | 7 | Drive Level Test Max Frequency |
| DLTLEVEL | number | 11 | 7 | Drive Level Test Low level |
| DLTANGLE | number | 11 | 7 | Drive Level Test Angle |
| ULIMSFRQ | number | 15 | 7 | Upper limit series frequency specification |
| ULIMLFR1 | number | 15 | 7 | Upper limit load frequency[0] specification |
| ULIMLFR2 | number | 15 | 7 | Upper limit load frequency[1] specification |
| ULIMLFR3 | number | 15 | 7 | Upper limit load frequency[2] specification |
| ULIMRES | number | 5 | 1 | Upper limit resistance specification |
| ULIML1 | number | 6 | 2 | Upper limit L1 specification |
| ULIMC1 | number | 6 | 3 | Upper limit C1 specification |
| ULIMC0 | number | 6 | 1 | Upper limit C0 specification |
| ULIMC0C1 | number | 6 | 1 | Upper limit C0/C1 ratio specification |
| ULIMQ | number | 6 | 1 | Upper limit Q specification |
| LLIMSFRQ | number | 15 | 7 | Lower limit series frequency specification |
| LLIMLFR1 | number | 15 | 7 | Lower limit load frequency[0] specification |
| LLIMLFR2 | number | 15 | 7 | Lower limit load frequency[1] specification |
| LLIMLFR3 | number | 15 | 7 | Lower limit load frequency[2] specification |
| LLIMRES | number | 5 | 1 | Lower limit resistance specification |
| LLIML1 | number | 6 | 2 | Lower limit L1 specification |
| LLIMC1 | number | 6 | 3 | Lower limit C1 specification |
| LLIMC0 | number | 6 | 1 | Lower limit C0 specification |
| LLIMC0C1 | number | 6 | 1 | Lower limit C0/C1 ratio specification |
| LLIMQ | number | 6 | 1 | Lower limit Q specification |
| AINIFREQ | number | 11 | 7 | Average Initial Frequency |
| AINIRES | number | 11 | 7 | Average Initial Resistance |
| ASERFREQ | number | 11 | 7 | Average Series Frequency |

| Name | Type | Length | Decimal | Description |
|----------|--------|--------|---------|-------------------------------|
| ALODFRQ1 | number | 11 | 7 | Average Load Frequency[0] |
| ALODFRQ2 | number | 11 | 7 | Average Load Frequency[1] |
| ALODFRQ3 | number | 11 | 7 | Average Load Frequency[2] |
| ATRIMS1 | number | 11 | 7 | Average Trim Sensitivity[0] |
| ATRIMS2 | number | 11 | 7 | Average Trim Sensitivity[1] |
| ATRIMS3 | number | 11 | 7 | Average Trim Sensitivity[2] |
| ARESIST | number | 11 | 7 | Average Resistance |
| AL1 | number | 11 | 7 | Average L1 |
| AC1 | number | 11 | 7 | Average C1 |
| AC0 | number | 11 | 7 | Average C0 |
| AC0C1 | number | 11 | 7 | Average C0/C1 |
| AQ | number | 11 | 7 | Average Q |
| SINIFREQ | number | 11 | 7 | Std Series Initial Frequency |
| SINITRES | number | 11 | 7 | Std Series Initial Resistance |
| SSERFREQ | number | 11 | 7 | Std Series Frequency |
| SLOFREQ1 | number | 11 | 7 | Std Load Frequency[0] |
| SLOFREQ2 | number | 11 | 7 | Std Load Frequency[1] |
| SLOFREQ3 | number | 11 | 7 | Std Load Frequency[2] |
| STRIMS1 | number | 11 | 7 | Std Trim Sensitivity[0] |
| STRIMS2 | number | 11 | 7 | Std Trim Sensitivity[1] |
| STRIMS3 | number | 11 | 7 | Std Trim Sensitivity[2] |
| SRESIST | number | 11 | 7 | Std Resistance |
| SL1 | number | 11 | 7 | Std L1 |
| SC1 | number | 11 | 7 | Std C1 |
| SC0 | number | 11 | 7 | Std C0 |
| SC0C1 | number | 11 | 7 | Std C0/C1 |
| SQ | number | 11 | 7 | Std Q |
| TFAILSFR | number | 5 | 0 | Total Passed |
| TFAILLF0 | number | 5 | 0 | Total Passed |
| TFAILLF1 | number | 5 | 0 | Total Passed |
| TFAILLF2 | number | 5 | 0 | Total Passed |
| TFAILRES | number | 5 | 0 | Total Passed |
| TFAILINF | number | 5 | 0 | Total Passed |
| TFAILINR | number | 5 | 0 | Total Passed |
| TFAILL1 | number | 5 | 0 | Total Passed |
| TFAILC1 | number | 5 | 0 | Total Passed |
| TFAILC0 | number | 5 | 0 | Total Passed |
| TFLECO1 | number | 5 | 0 | Total Passed |
| TFAILQ | number | 5 | 0 | Total Passed |
| TFAILDTF | number | 5 | 0 | Total Passed |

| Name | Type | Length | Decimal | Description |
|----------|--------|--------|---------|--------------|
| TFAILDTR | number | 5 | 0 | Total Passed |

The Item file (DBF) has one record for every measurement performed. The format of the file is shown in the following table.

| Name | Type | Length | Decimal | Description |
|----------|--------|--------|---------|--|
| LOTNAME | string | 15 | 0 | Lot Name |
| SERNUMBR | string | 15 | 0 | Serial Number |
| TARGFREQ | number | 11 | 7 | Target Frequency (in MHz) |
| INITFREQ | number | 11 | 7 | Initial Frequency (in MHz) |
| INITRES | number | 11 | 7 | Initial Resistance (in ohms) |
| CALCTARG | number | 11 | 7 | Calculated Target Freq (in MHz) |
| MEASTYPE | number | 2 | 0 | Measurement Type |
| FREQ | number | 11 | 7 | Measured Frequency (in MHz) |
| LOADFRQ1 | number | 11 | 7 | Measured Load Frequency[0] (in MHz) |
| LOADFRQ2 | number | 11 | 7 | Measured Load Frequency[1] (in MHz) |
| LOADFRQ3 | number | 11 | 7 | Measured Load Frequency[2] (in MHz) |
| TRIMS1 | number | 11 | 7 | Trim Sensitivity[0] (in ppm/pF) |
| TRIMS2 | number | 11 | 7 | Trim Sensitivity[1] (in ppm/pF) |
| TRIMS3 | number | 11 | 7 | Trim Sensitivity[2] (in ppm/pF) |
| RESIST | number | 11 | 7 | Measured Resistance (in ohms) |
| L1 | number | 11 | 7 | Inductance of motional branch (in mH) |
| C1 | number | 11 | 7 | Capacitance of motional branch (in fF) |
| C0 | number | 11 | 7 | Static Capacitance (in pF) |
| C0/C1 | number | 11 | 7 | Ratio of C0 to C1 (in pF) |
| Q | number | 11 | 7 | Quality Factor (in 1000s) |
| LCKANGLE | number | 11 | 7 | Measured Lock Angle (in degrees) |
| DC | number | 11 | 7 | Measured Drive Current (in mA) |
| DP | number | 11 | 7 | Measured Drive Power (in mW) |
| TESTRSLT | string | 5 | 0 | Test Result against specifications |
| EDLTRES | number | 11 | 7 | |
| EDLTFREQ | number | 11 | 7 | |
| ERESPCT | number | 11 | 7 | percentage error calculated for these item |
| EL1PCT | number | 11 | 7 | |
| EC1PCT | number | 11 | 7 | |
| EC0PCT | number | 11 | 7 | |
| EC0C1PCT | number | 11 | 7 | |
| EQPCT | number | 11 | 7 | |
| EINIFREQ | number | 11 | 7 | |
| EINIRES | number | 11 | 7 | |

| Name | Type | Length | Decimal | Description |
|----------|--------|--------|---------|--|
| ESERFREQ | number | 11 | 5 | |
| ELODFRQ1 | number | 11 | 5 | |
| ELODFRQ2 | number | 11 | 5 | |
| ELODFRQ3 | number | 11 | 5 | |
| FAILRES | number | 1 | 0 | spec failure flags |
| FAILL1 | number | 1 | 0 | |
| FAILC1 | number | 1 | 0 | |
| FAILC0 | number | 1 | 0 | |
| FAILC0C1 | number | 1 | 0 | |
| FAILQ | number | 1 | 0 | |
| FAILFRQ | number | 1 | 0 | |
| FAILRES | number | 1 | 0 | |
| FAILSFRQ | number | 1 | 0 | |
| FAILFR1 | number | 1 | 0 | |
| FAILFR2 | number | 1 | 0 | |
| FAILFR3 | number | 1 | 0 | |
| FAILDLTR | number | 1 | 0 | |
| FAILDLTF | number | 1 | 0 | |
| STARTDTE | string | 12 | 0 | Start Plating Date (DD Mmm YYYY) |
| STARTTME | string | 9 | 0 | Start Plating Time (HH:MM:SS) |
| STOPDTE | string | 12 | 0 | Stop Plating Date (DD Mmm YYYY) |
| STOPTME | string | 9 | 0 | Stop Plating Time (HH:MM:SS) |
| STTIME | number | 12 | 0 | Elapsed time since start of application at start of item |
| ENDTIME | number | 12 | 0 | Elapsed time since start of application at end of item |
| ELAPTIME | number | 11 | 1 | Elapsed time (in seconds) |
| PLTMAGER | number | 6 | 0 | Encoded error from Platemgr |

APPENDIX D USING R&R REPORT WRITER® TO CUSTOMIZE REPORTS

External reports are batch files that you create that are automatically run after a production test ends. The batch file is a single line MS-DOS batch file with a .EXT file extension. An example method using the R&R Report Writer® is described in this section.

To make a custom report

1. Make a report template and report library (both must have the same name) using R&R REPORT WRITER. See the R&R manual.
2. Create an .EXT file. It should only contain 1 line which will cause a Batch file to run.

For example:

```
call mulcol
```

3. Create the Batch file (the name of the batch file was specified in Step 2). The Batch File name must have an .BAT extension. In the example in Step 2, the Batch file is named MULCOL.BAT.

Your Batch file should basically be the same as the following example, except place the name of your report in <REPORT_NAME>.

```
@echo off
dbfcvt -q -i%1 -o%1
rrcreate -q -r<REPORT_NAME> -l%1
..\rr\rruntime rrunin
```

where:

```
@echo off (turns off the display).
```

```
dbfcvt -q -i%1 -o%1 (converts the CNA item information to dBASE format).
```

```
rrcreate -q -r<REPORT_NAME> -l%1 (creates the R&R control file which contains the name (<REPORT_NAME>) of the final report and the report library. The name of the control file is rrunin.).
```

```
..\rr\rruntime rrunin (runs the R&R runtime program, which takes the contents of rrunin to create your customized report).
```

4. From the Main menu, press <4>. The Configure System menu will display.
5. Press <2>. The Print/Log Setup menu will display.
6. Enable (set to 1) External Reports.
7. Enter the name of the .EXT file you created in Step 2.

APPENDIX E CREATING CUSTOM REPORTS USING SCRIPT FILES

This appendix describes how you can create templates to customize reports. Using this method, you can select which measurement data you need in a report, and how it is presented.

The system supports a general purpose report writing facility that allows users to generate fast easy custom reports. You need to create a Script file (with an extension of .SCR) for each type of report you wish to generate.

To use your Script file

1. From the Main menu, press <4>. The Configure System menu will display.
2. Press <2>. The Print/Log Setup menu will display.
3. Enable (set to 1) Script Reports.
4. Enter the name of the Script file (.SCR) you created.

If your directory is not the directory the system software is in, then you will need to specify the filepath of your EXT file.

1. From the Main menu press <4>. The Configure System menu will display.
2. Press <4>. The Internal Parameters menu will display.
3. Press <6>, and change the External Report File Path.

Enter the path where the external report is located.

In a Script file you will need to specify these sections:

- HEADER
- ITEM
- SUMMARY
- PAGE HEADER

When a customized report is generated (from the Script file), you will see the following:

- The Header section printed only once, at the beginning of the report.
- The Item section printed for every item, or device, measured during the test run
- The Summary section printed at the end of the report.
- The Page Header section printed at the beginning of every page.

These sections are generated using the ID numbers of the parameters in the Lot and Item files. These files were generated by the system while tests were being performed. The ID numbers are listed in the following table.

| ID | Name | Type | Length | Scalar | Description |
|-----|------------------|----------|-----------|--------|--------------|
| 100 | IDI_LOT_NAME | STR_TYPE | "%s" | 1 | Lot_Name |
| 101 | IDI_SERIALNUMBER | STR_TYPE | "%s" | 1 | SerialNumber |
| 102 | IDI_TARGETFREQ | DBL_TYPE | "%10.6lf" | 1 | TargetFreq |
| 103 | IDI_INITIALFREQ | DBL_TYPE | "%10.6lf" | 1 | InitialFreq |

| ID | Name | Type | Length | Scalar | Description |
|-----|----------------------|----------|-----------|--------|--------------------|
| 104 | IDI_INITIALRES | DBL_TYPE | "%6.2lf" | 1 | InitialRes |
| 105 | IDI_CALCARGET | DBL_TYPE | "%10.6lf" | 1 | CalcTarget |
| 106 | IDI_MEASURETYPE | INT_TYPE | "%d" | 1 | MeasureType |
| 107 | IDI_FREQUENCY | DBL_TYPE | "%10.6lf" | 1 | Frequency |
| 108 | IDI_LOADFREQUENCY1 | DBL_TYPE | "%10.6lf" | 1 | LoadFrequency[0] |
| 109 | IDI_LOADFREQUENCY2 | DBL_TYPE | "%10.6lf" | 1 | LoadFrequency[1] |
| 110 | IDI_LOADFREQUENCY3 | DBL_TYPE | "%10.6lf" | 1 | LoadFrequency[2] |
| 111 | IDI_TRIMSENSITIVITY1 | DBL_TYPE | "%6.2lf" | 1 | TrimSensitivity[0] |
| 112 | IDI_TRIMSENSITIVITY2 | DBL_TYPE | "%6.2lf" | 1 | TrimSensitivity[1] |
| 113 | IDI_TRIMSENSITIVITY3 | DBL_TYPE | "%6.2lf" | 1 | TrimSensitivity[2] |
| 114 | IDI_RESISTANCE | DBL_TYPE | "%6.1lf" | 1.0 | Resistance |
| 115 | IDI_L1 | DBL_TYPE | "%8.3lf" | 1.0 | L1 |
| 116 | IDI_C1 | DBL_TYPE | "%8.4lf" | 1.0 | C1 |
| 117 | IDI_C0 | DBL_TYPE | "%7.1lf" | 1.0 | C0 |
| 118 | IDI_Q | DBL_TYPE | "%7.0lf" | 1.0 | Q |
| 119 | IDI_LOCKANGLE | DBL_TYPE | "%7.1lf" | 1.0 | LockAngle |
| 120 | IDI_DC | DBL_TYPE | "%7.3lf" | 1.0 | DC |
| 121 | IDI_DP | DBL_TYPE | "%7.3lf" | 1.0 | DP |
| 122 | IDI_TESTRESULT | STR_TYPE | "%s" | 1.0 | TestResult |
| 123 | IDI_DLT_RESERR | DBL_TYPE | "%6.1lf" | 1.0 | DLT_ResErr |
| 124 | IDI_DLT_FREQERR | DBL_TYPE | "%6.1lf" | 1.0 | DLT_FreqErr |
| 125 | IDI_ERRRESISTPCT | DBL_TYPE | "%6.2lf" | 1.0 | ErrResistPct |
| 126 | IDI_ERRL1PCT | DBL_TYPE | "%6.2lf" | 1.0 | ErrL1Pct |
| 127 | IDI_ERRC1PCT | DBL_TYPE | "%6.2lf" | 1.0 | ErrC1Pct |
| 128 | IDI_ERRC0PCT | DBL_TYPE | "%6.2lf" | 1.0 | ErrC0Pct |
| 129 | IDI_ERRQPCT | DBL_TYPE | "%6.2lf" | 1.0 | ErrQPct |
| 130 | IDI_ERRINITIALFREQ | DBL_TYPE | "%6.2lf" | 1.0 | ErrInitialFreq |
| 131 | IDI_ERRINITIALRES | DBL_TYPE | "%6.2lf" | 1.0 | ErrInitialRes |
| 132 | IDI_ERRSERFREQ | DBL_TYPE | "%6.2lf" | 1.0 | ErrSerFreq |
| 133 | IDI_ERRLOADFREQ1 | DBL_TYPE | "%6.2lf" | 1.0 | ErrLoadFreq[0] |
| 134 | IDI_ERRLOADFREQ2 | DBL_TYPE | "%6.2lf" | 1.0 | ErrLoadFreq[1] |
| 135 | IDI_ERRLOADFREQ3 | DBL_TYPE | "%6.2lf" | 1.0 | ErrLoadFreq[2] |
| 136 | IDI_FAILRESIST | INT_TYPE | "%d" | 1.0 | FailResist |
| 137 | IDI_FAILL1 | INT_TYPE | "%d" | 1.0 | FailL1 |
| 138 | IDI_FAILC1 | INT_TYPE | "%d" | 1 | IDI_FAILC1 |
| 139 | IDI_FAILC0 | INT_TYPE | "%d" | 1.0 | FailC0 |
| 140 | IDI_FAILQ | INT_TYPE | "%d" | 1.0 | FailQ |
| 141 | IDI_FAILINITIALFREQ | INT_TYPE | "%d" | 1.0 | FailInitialFreq |
| 142 | IDI_FAILINITIALRES | INT_TYPE | "%d" | 1.0 | FailInitialRes |
| 143 | IDI_FAILSERFREQ | INT_TYPE | "%d" | 1.0 | FailSerFreq |

| ID | Name | Type | Length | Scalar | Description |
|-----|-------------------|----------|----------|--------|-----------------|
| 144 | IDI_FAILLOADFREQ1 | INT_TYPE | "%d" | 1.0 | FailLoadFreq[0] |
| 145 | IDI_FAILLOADFREQ2 | INT_TYPE | "%d" | 1.0 | FailLoadFreq[1] |
| 146 | IDI_FAILLOADFREQ3 | INT_TYPE | "%d" | 1.0 | FailLoadFreq[2] |
| 147 | IDI_FAILDLT_R | INT_TYPE | "%d" | 1.0 | FailDLT_R |
| 148 | IDI_FAILDLT_F | INT_TYPE | "%d" | 1.0 | FailDLT_F |
| 149 | IDI_STARTDATE | STR_TYPE | "%s" | 1.0 | StartDate |
| 150 | IDI_STARTTIME | STR_TYPE | "%s" | 1.0 | StartTime |
| 151 | IDI_STOPDATE | STR_TYPE | "%s" | 1.0 | StopDate |
| 152 | IDI_STOPTIME | STR_TYPE | "%s" | 1.0 | StopTime |
| 153 | IDI_ST_TIME | LNG_TYPE | "%ld" | 1.0 | st_time |
| 154 | IDI_END_TIME | LNG_TYPE | "%ld" | 1.0 | end_time |
| 155 | IDI_ELAPTIME | DBL_TYPE | "%s" | 1.0 | elaptime |
| 156 | IDI_PLTMAGERR | INT_TYPE | "%d" | 1.0 | pltmagerr |
| 157 | IDI_C0C1 | DBL_TYPE | "%7.11f" | 1 | C0C1 |
| 158 | IDI_ERRC0C1 | DBL_TYPE | "6.2LF" | 1 | ErrC0C1 |
| 159 | IDI_FAILC0C1 | INT_TYPE | "%d" | 1 | FailC0C1 |

Each item in the Lot and Item files have a unique ID # that allows it to be specified. In addition, each item has a default format, in C language printf style, to allow default output formats. Each item can be scaled with an additional parameter to achieve more reasonable displays.

Each section contains:

- An image section that is a picture of what the output should look like with position identifiers for locating the data items.
- A data ID section that identifies which parameters to display, and also allows insertion of control commands to forced pagination or line control.

The following is an example of an SCR file. Note that a line containing only a number is specifying that the parameter with that ID# should be placed here.

 This is the sample header section. Fields that are located here are typically lot specific information like items found in the 'lot' information.

```
.HBEGIN                                <- header section delimiter
System File      : ^
Log File        : ^
Date            : ^
Time           : ^
Run Time       : ^
Total Tested   : ^
Total Passed   : ^
Total Failed   : ^

Target Freq    : ^
ESR           : ^
Drive Power    : ^
```

```
Specification
  Max F      : ^
  Min F      : ^
  Max R      : ^

.end          <- End of image section of Header section
201          <- these data items use the default format
200
225
226
231
220
221
222
207 "%10.2lf" 0.5 <- this data item uses a special format & scale term
219
218
246
255
250
.page <- this forces a page break to start a new page
.end

.pbegim <- this is the delimiter for the start of the page header
THIS IS THE PAGE HEADER      NUM      FREQ      R
-----
.end
.end

.IBEGIM <- this starts the item section
THIS IS THE ITEM DATA. # = ^      Freq : ^      Resistance : ^
.end
101
107
114
.end

.SBEGIM <- this starts the summary section

System File : ^
Log File    : ^
Date        : ^
Time        : ^
Run Time    : ^
Total Tested : ^
Total Passed : ^
Total Failed : ^

Target Freq : ^
ESR          : ^
Drive Power  : ^

Specification
  Max F      : ^
  Min F      : ^
  Max R      : ^

.end
201
200
```

225
226
231
220
221
222
207
219
218
246
255
250
.end

The following is a list of all the available data items:

```
#ifndef CUSTMRPT_H
#define CUSTMRPT_H
```

```
/*   custmrpt.h
```

Defines for file driven customized report generator.
Each data item available for output to the report file is assigned a unique identifier. The report consists of a "lot" header output when plating begins, item info output after each part is plated and a "lot" summary output after the last cpart in the "lot" is plated.

By definition a lot is the group of parts specified by the start magazine and carrier positions and number of parts to plate command.

Content and format of each section is defined in report definition files. Each line in the file is a data ID and printf format for that data item.

NOTE

The printf format should not include escape sequence characters such as \n, \t, \f, etc. The scanf function prepends these with a "\" and they are then not properly interpreted by the fprintf function.

For now separate filed codes are used to output a \n or \f

```
#define STR_TYPE 0
#define INT_TYPE 1
#define DBL_TYPE 2
#define LNG_TYPE 3

struct idmap {
    int id;
    void *param;
    int type;
    char dfltfmt[20];
    double dfltscale;
};

#define MAXFMTSZ 130      /* max format string length */

/*****
    NEVER NEVER NEVER change, remove, or re-use identifiers
*****/

#define ID_COMMENT        -1 /* We DO support comments in the files */
#define ID_NEWLINE        -2 /* "\n" */
#define ID_FORMFEED       -3 /* "\f" */

#define ID_NULL           0 /* string only in format, no data */

#define ID_SYSVERSION     1
#define ID_SYSBUILDDATE   2
#define ID_SYSBUILDTIME   3

#define ID_SCRIPTFILEPATH 18
#define ID_SCRIPTFILENAME 19
#define ID_SCRIPTITMFILENAME 20
#define ID_SCRIPTSUMFILENAME 21
```

```
#define ID_CURRENTDATE      56
#define ID_CURRENTTIME     57
```

The following table lists the Lot File parameters available:

| ID | Name | Type | Length | Scalar | Description |
|-----|-----------------------|----------|-----------|--------|-------------------|
| 200 | IDL_LOGFILENAME | STR_TYPE | "%s" | 1.0 | LogFileName |
| 201 | IDL_SYSFILENAME | STR_TYPE | "%s" | 1.0 | SysFileName |
| 202 | IDL_MCTFILENAME | STR_TYPE | "%s" | 1.0 | MCTFileName |
| 203 | IDL_LOGFILEPATH | STR_TYPE | "%s" | 1.0 | LogFilePath |
| 204 | IDL_SYSFILEPATH | STR_TYPE | "%s" | 1.0 | SysFilePath |
| 205 | IDL_MCTFILEPATH | STR_TYPE | "%s" | 1.0 | MCTFilePath |
| 206 | IDL_RPTFMT | INT_TYPE | "%d" | 1 | rptfmt |
| 207 | IDL_TARGETFREQ | DBL_TYPE | "%10.6lf" | 1.0 | TargetFreq |
| 208 | IDL_LOADCAPMODE | INT_TYPE | "%d" | 1.0 | LoadCapMode |
| 209 | IDL_LOADFREQ0 | DBL_TYPE | "%10.6lf" | 1.0 | LoadFreq[0] |
| 210 | IDL_LOADFREQ1 | DBL_TYPE | "%10.6lf" | 1.0 | LoadFreq[1] |
| 211 | IDL_LOADFREQ2 | DBL_TYPE | "%10.6lf" | 1.0 | .LoadFreq[2] |
| 212 | IDL_TARGETCAP0 | DBL_TYPE | "%7.3lf" | 1.0 | TargetCap[0] |
| 213 | IDL_TARGETCAP1 | DBL_TYPE | "%7.3lf" | 1.0 | TargetCap[1] |
| 214 | IDL_TARGETCAP2 | DBL_TYPE | "%7.3lf" | 1.0 | TargetCap[2] |
| 215 | IDL_CL2_REF | DBL_TYPE | "%7.3lf" | 1.0 | CL2_Ref |
| 216 | IDL_CL3_REF | DBL_TYPE | "%7.3lf" | 1.0 | CL3_Ref |
| 217 | IDL_INSERTCAP | DBL_TYPE | "%7.3lf" | 1 | InsertCap |
| 218 | IDL_DRIVEPOWER | DBL_TYPE | "%7.3lf" | 1.0 | DrivePower |
| 219 | IDL_ESR | DBL_TYPE | "%7.3lf" | 1.0 | ESR |
| 220 | IDL_PLATINGATTEMPTS | INT_TYPE | "%d" | 1.0 | PlatingAttempts |
| 221 | IDL_TOTALPASSED | INT_TYPE | "%d" | 1.0 | TotalPassed |
| 222 | IDL_TOTALFAILED | INT_TYPE | "%d" | 1.0 | TotalFailed |
| 223 | IDL_POSTPLATEMEASERR | INT_TYPE | "%d" | 1.0 | PostPlateMeasErr |
| 224 | IDL_POSTPLATESPECFAIL | INT_TYPE | "%d" | 1.0 | PostPlateSpecFail |
| 225 | IDL_STARTDATE | STR_TYPE | "%s" | 1.0 | StartDate |
| 226 | IDL_STARTTIME | STR_TYPE | "%s" | 1 | StartTime |
| 227 | IDL_STOPDATE | STR_TYPE | "%s" | 1.0 | StopDate |
| 228 | IDL_STOPTIME | STR_TYPE | "%s" | 1.0 | StopTime |
| 229 | IDL_ST_TIME | LNG_TYPE | "%ld" | 1 | st_time |
| 230 | IDL_END_TIME | LNG_TYPE | "%ld" | 1.0 | end_time |
| 231 | IDL_ELAPTIME | LNG_TYPE | "%ld" | 1.0 | elaptime |
| 232 | IDL_NOMSERENB | INT_TYPE | "%d" | 1.0 | NomSerEnb |
| 233 | IDL_NOMLOADENB0 | INT_TYPE | "%d" | 1.0 | NomLoadEnb[0] |
| 234 | IDL_NOMLOADENB1 | INT_TYPE | "%d" | 1 | NomLoadEnb[1] |
| 235 | IDL_NOMLOADENB2 | INT_TYPE | "%d" | 1.0 | NomLoadEnb[2] |

| ID | Name | Type | Length | Scalar | Description |
|-----|--------------------|----------|-----------|--------|-----------------|
| 236 | IDL_NOMRESISTEN | INT_TYPE | "%d" | 1.0 | NomResistEn |
| 237 | IDL_NOML1ENB | INT_TYPE | "%d" | 1.0 | NomL1Enb |
| 238 | IDL_NOMC1ENB | INT_TYPE | "%d" | 1.0 | NomC1Enb |
| 239 | IDL_NOMC0ENB | INT_TYPE | "%d" | 1.0 | NomC0Enb |
| 240 | IDL_NOMQENB | INT_TYPE | "%d" | 1.0 | NomQEnb |
| 241 | IDL_DLT_ENABLED | INT_TYPE | "%d" | 1.0 | DLT_Enabled |
| 242 | IDL_DLT_MAXR | DBL_TYPE | "%7.31f" | 1.0 | DLT_MaxR |
| 243 | IDL_DLT_MAXF | DBL_TYPE | "%7.31f" | 1.0 | DLT_MaxF |
| 244 | IDL_DLT_LEVEL | DBL_TYPE | "%7.31f" | 1.0 | DLT_Level |
| 245 | IDL_DLT_ANGLE | DBL_TYPE | "%7.31f" | 1.0 | DLT_Angle |
| 246 | IDL_ULIMSERFREQ | DBL_TYPE | "%7.31f" | 1.0 | ULimSerFreq |
| 247 | IDL_ULIMLOADFREQ0 | DBL_TYPE | "%7.31f" | 1.0 | ULimLoadFreq[0] |
| 248 | IDL_ULIMLOADFREQ1 | DBL_TYPE | "%7.31f" | 1 | ULimLoadFreq[1] |
| 249 | IDL_ULIMLOADFREQ2 | DBL_TYPE | "%7.31f" | 1.0 | ULimLoadFreq[2] |
| 250 | IDL_ULIMRESISTPCT | DBL_TYPE | "%7.31f" | 1.0 | ULimResistPct |
| 251 | IDL_ULIML1PCT | DBL_TYPE | "%7.31f" | 1.0 | ULimL1Pct |
| 252 | IDL_ULIMC1PCT | DBL_TYPE | "%7.31f" | 1.0 | ULimC1Pct |
| 253 | IDL_ULIMC0PCT | DBL_TYPE | "%7.31f" | 1.0 | ULimC0Pct |
| 254 | IDL_ULIMQPCT | DBL_TYPE | "%7.31f" | 1.0 | ULimQPct |
| 255 | IDL_LLMISERFREQ | DBL_TYPE | "%7.31f" | 1.0 | LLimSerFreq |
| 256 | IDL_LLMLOADFREQ0 | DBL_TYPE | "%7.31f" | 1.0 | LLimLoadFreq[0] |
| 257 | IDL_LLMLOADFREQ1 | DBL_TYPE | "%7.31f" | 1.0 | LLimLoadFreq[1] |
| 258 | IDL_LLMLOADFREQ2 | DBL_TYPE | "%7.31f" | 1.0 | LLimLoadFreq[2] |
| 259 | IDL_LLMRESISTPCT | DBL_TYPE | "%7.31f" | 1 | LLimResistPct |
| 260 | IDL_LLIML1PCT | DBL_TYPE | "%7.31f" | 1.0 | LLimL1Pct |
| 261 | IDL_LLIMC1PCT | DBL_TYPE | "%7.31f" | 1.0 | LLimC1Pct |
| 262 | IDL_AVGINITIALFREQ | DBL_TYPE | "%10.61f" | 1.0 | AvgInitialFreq |
| 263 | IDL_AVGINITIALRES | DBL_TYPE | "%7.11f" | 1.0 | AvgInitialRes |
| 264 | IDL_AVGSERFREQ | DBL_TYPE | "%10.61f" | 1 | AvgSerFreq |
| 265 | IDL_AVGLOADFREQ0 | DBL_TYPE | "%10.61f" | 1.0 | AvgLoadFreq[0] |
| 266 | IDL_AVGLOADFREQ1 | DBL_TYPE | "%10.61f" | 1.0 | AvgLoadFreq[1] |
| 267 | IDL_AVGLOADFREQ2 | DBL_TYPE | "%10.61f" | 1.0 | AvgLoadFreq[2] |
| 268 | IDL_AVGTRIMSENS0 | DBL_TYPE | "%7.31f" | 1.0 | AvgTrimSens[0] |
| 269 | IDL_AVGTRIMSENS1 | DBL_TYPE | "%7.31f" | 1.0 | AvgTrimSens[1] |
| 270 | IDL_AVGTRIMSENS2 | DBL_TYPE | "%7.31f" | 1.0 | AvgTrimSens[2] |
| 271 | IDL_AVGRESIST | DBL_TYPE | "%7.11f" | 1.0 | AvgResist |
| 272 | IDL_AVGL1 | DBL_TYPE | "%7.31f" | 1.0 | AvgL1 |
| 273 | IDL_AVGC1 | DBL_TYPE | "%8.41f" | 1.0 | AvgC1 |
| 274 | IDL_AVGC0 | DBL_TYPE | "%7.11f" | 1.0 | AvgC0 |
| 275 | IDL_AVGQ | DBL_TYPE | "%7.01f" | 1.0 | AvgQ |

| ID | Name | Type | Length | Scalar | Description |
|-----|--------------------|-----------|----------|--------|----------------|
| 276 | IDL_STDINITIALFREQ | DBL_TYPE | "%7.3lf" | 1.0 | StdInitialFreq |
| 277 | IDL_STDINITIALRES | DBL_TYPE | "%7.3lf" | 1.0 | StdInitialRes |
| 278 | IDL_STDSERFREQ | DBL_TYPE | "%7.3lf" | 1.0 | StdSerFreq |
| 279 | IDL_STDLLOADFREQ0 | DBL_TYPE | "%7.3lf" | 1.0 | StdLoadFreq[0] |
| 280 | IDL_STDLLOADFREQ1 | DBL_TYPE | "%7.3lf" | 1.0 | StdLoadFreq[1] |
| 281 | IDL_STDLLOADFREQ2 | DBL_TYPE | "%7.3lf" | 1.0 | StdLoadFreq[2] |
| 282 | IDL_STDTRIMSENS0 | DBL_TYPE | "%7.3lf" | 1.0 | StdTrimSens[0] |
| 283 | IDL_STDTRIMSENS1 | DBL_TYPE | "%7.3lf" | 1.0 | StdTrimSens[1] |
| 284 | IDL_STDTRIMSENS2 | DBL_TYPE | "%7.3lf" | 1.0 | StdTrimSens[2] |
| 285 | IDL_STDRESIST | DBL_TYPE | "%7.3lf" | 1.0 | StdResist |
| 286 | IDL_STDL1 | DBL_TYPE, | "%7.3lf" | 1.0 | StdL1 |
| 287 | IDL_STDC1 | DBL_TYPE | "%7.3lf" | 1.0 | StdC1 |
| 288 | IDL_STDC0 | DBL_TYPE | "%7.3lf" | 1.0 | StdC0 |
| 289 | IDL_STDQ | DBL_TYPE | "%7.3lf" | 1.0 | StdQ |
| 290 | IDL_LLIMC0PCT | DBL_TYPE | "%7.3lf" | 1.0 | LLimC0Pct |
| 291 | IDL_LLIMQPCT | DBL_TYPE | "%7.3lf" | 1.0 | LLimQPct |
| 292 | IDL_LLIMC0C1 | DBL_TYPE | "%7.3lf" | 1.0 | LLimC0C1 |
| 293 | IDL_ULIMC0C1 | DBL_TYPE | "%7.3lf" | 1.0 | ULimC0C1 |
| 294 | IDL_NOMCOC1ENB | INT_TYPE | "%d" | 1.0 | NomC0C1Enb |
| 295 | IDL_STDCOC1 | DBL_TYPE | "%7.3lf" | 1.0 | StdC0C1 |
| 296 | IDL_AVGC0C1 | DBL_TYPE | "%7.1lf" | 1.0 | AvgC0C1 |

APPENDIX F SYSTEM MENUS

The following lists the system menus and where they can be accessed.

Main System menu

1. Run Test
 - F1. Start
 - F2. Edit
 - F3. Add
 - F4. Delete
 - F5. Del All
2. Setup Test
 - F1. Start
 - F2. Modify
 - F1. Start
 - F2. Edit
 - F3. Add
 - F4. Delete
 - F5. Del All
 - F3. Measpar
 - F4. Load
 - F5. Save
 - F6. Create
 - F7. Delete
3. View Data
 1. Select Data Set
 2. Display Data
 3. Print Data
 4. Display Distributions
 5. Print Distributions
 6. Modify Test Specifications
 - F1. Edit
 - F2. Add
 - F3. Delete
 - F4. Del All
 7. Re-generate Test Report
 8. Export Test Data
 9. Delete Log File
4. Configure System
 1. Calibrate Instrument
 2. Print/Log File Maintenance
 1. Modify Setup
 2. View Log File
 3. Print Log File
 4. Delete Log File
 5. Select Script File
 6. Select External File
 3. Quick Measure Mode
 1. Make Measurement
 2. Change Current Setup
 3. Measurement Parameters
 4. Sweep Control
 1. Set Sweep Begin
 2. Set Sweep End
 3. Go to Sweep Begin (CNA 300)
 4. Go to Sweep End (CNA 300)

5. Display Sweep
 6. Sweep Parameters
 1. Modify Plot Setup
 2. Modify Printer Setup
 3. Display Plot
 4. Save Plot Setup
 7. File Maintenance
 1. View Log File
 2. Print Log File
 3. Create Log File
 4. Delete Log File
 5. Load Setup
 6. Save Setup
 7. Create Setup
 8. Delete Setup
 8. Internal Parameters
 1. System Parameters
 2. Digital I/O Parameters
 3. External Parameters
 4. FFC Card Parameters (CNA 300)
 5. Calibration File Maintenance
 6. File Path Maintenance
 7. Calibrate Instrument
 8. Alternative Spurious Search
4. Internal Parameters
 1. System Parameters
 2. Digital I/O Parameters
 3. External Parameters
 4. FFC Card Parameters (CNA 300)
 5. Calibration File Maintenance
 6. File Path Maintenance
 7. Plating Rate Control Parameters (CNA 300)
 8. Alternative Spurious Search

APPENDIX G SAMPLE REPORTS

This section contains several sample print reports showing the different type of formats when different tests are selected.

NOTE These printouts do not indicate failed parameters with PASS or FAIL as was displayed on the screen when you ran the tests. An asterisk (*) indicates PASS or FAIL.

Report with Frequency Test ONLY

TRANSAT Measurement System LOT REPORT Date : August 31, 1995 Time : 06:34 PM

Lot Setup:
 Log File Name : MTEST
 System File : MTEST
 Calibration File : SYSTEM
 Report Type : COMPLETE
 Target Freq MHz : 10.000000
 Load CL Mode : SERIES
 Insert CL pF : 0.00

Specifications:

| Series F | Enable | Upper | Lower |
|----------|--------|-------|--------|
| | 1 | 200.0 | -200.0 |

TRANSAT Measurement System LOT REPORT Current Date : August 31, 1995 Time : 06:34 PM
 Lot Name : MTEST

| Serial Number | F | Err ppm | DP(uW) |
|---------------|-----------|---------|--------|
| CNA300_1 | 9.9983578 | -164.2 | 96.89 |
| CNA300_2 | 9.9983577 | -164.2 | 97.08 |
| CNA300_3 | 9.9983577 | -164.2 | 97.07 |
| CNA300_4 | 9.9983577 | -164.2 | 97.07 |
| CNA300_5 | 9.9983577 | -164.2 | 97.07 |
| CNA300_6 | 9.9983577 | -164.2 | 97.07 |
| CNA300_7 | 9.9983576 | -164.2 | 97.06 |
| CNA300_8 | 9.9983576 | -164.2 | 97.07 |
| CNA300_9 | 9.9983576 | -164.2 | 97.07 |
| CNA300_10 | 9.9983576 | -164.2 | 97.09 |

TRANSAT Measurement System LOT REPORT Date : August 31, 1995 Time : 06:34 PM

Performance Summary:
 Run Date : 31 Aug 1995 Start : 18:33:57 Stop : 18:34:18
 Number of Measurements made : 10
 Total number that passed specifications : 10
 Total number that failed specifications : 0
 Total number of measurement errors : 0
 Total number of specification failures : 0

| | AVG | STD |
|----------|-----------|-----------|
| Series F | 9.9983577 | 0.0000001 |

Report with Frequency, Resistance, L1, C1, C0, C0/C1 and Q Tests

TRANSAT Measurement System LOT REPORT Date : November 8, 1996 Time : 10:46 AM

Lot Setup:
 Log File Name : logfile
 System File : SYSFILE
 Calibration File : SYSTEM
 Report Type : COMPLETE
 Target Freq MHz : 9.997000
 Load CL Mode : SERIES
 Insert CL pF : 12.00

Specifications:

| | Enable | Upper | Lower |
|----------|--------|--------|-------|
| Series F | 1 | 100.0 | 0.0 |
| R | 1 | 15.0 | 0.0 |
| L1 | 1 | 40.0 | 0.0 |
| C1 | 1 | 26.000 | 0.000 |
| C0 | 1 | 4.1 | 1.1 |
| Q | 1 | 100.0 | 0.0 |
| C0/C1 | 1 | 400.0 | 100.0 |

TRANSAT Measurement System LOT REPORT Current Date : November 8, 1996 Time : 10:46 AM
 Lot Name : SYSFILE

| Serial Number | F | Err ppm | R | L1 | C1 (fF) | C0 (pF) | Q | DP(uW) | C0/C1 |
|---------------|-----------|---------|------|--------|---------|---------|------|---------|--------|
| TRANSAT_1 | 9.9976991 | 69.9 | 13.4 | 16.544 | 15.318 | 1.86 | 77.8 | 122.847 | 121.23 |
| TRANSAT_2 | 9.9976990 | 69.9 | 13.4 | 16.582 | 15.283 | 1.86 | 77.9 | 122.893 | 121.51 |
| TRANSAT_3 | 9.9976992 | 69.9 | 13.4 | 16.564 | 15.299 | 1.86 | 77.5 | 123.057 | 121.38 |
| TRANSAT_4 | 9.9976991 | 69.9 | 13.4 | 16.484 | 15.374 | 1.86 | 77.2 | 122.981 | 120.78 |
| TRANSAT_5 | 9.9976991 | 69.9 | 13.4 | 16.580 | 15.285 | 1.86 | 77.6 | 123.032 | 121.49 |
| TRANSAT_6 | 9.9976992 | 69.9 | 13.4 | 16.593 | 15.273 | 1.86 | 77.6 | 123.072 | 121.59 |
| TRANSAT_7 | 9.9976992 | 69.9 | 13.4 | 16.566 | 15.297 | 1.86 | 77.5 | 123.051 | 121.39 |
| TRANSAT_8 | 9.9976992 | 69.9 | 13.4 | 16.575 | 15.289 | 1.85 | 77.5 | 123.048 | 121.24 |
| TRANSAT_9 | 9.9976991 | 69.9 | 13.4 | 16.631 | 15.238 | 1.86 | 77.8 | 123.066 | 121.87 |
| TRANSAT_10 | 9.9976991 | 69.9 | 13.4 | 16.584 | 15.281 | 1.86 | 77.6 | 123.048 | 121.52 |

TRANSAT Measurement System LOT REPORT Date : November 8, 1996 Time : 10:47 AM

Performance Summary:

Run Date : 8 Nov 1996 Start : 10:46:51 Stop : 10:47:06
 Number of Measurements made : 10
 Total number that passed specifications : 10
 Total number that failed specifications : 0
 Total number of measurement errors : 0
 Total number of specification failures : 0

| | AVG | STD |
|----------|-----------|-----------|
| Series F | 9.9976991 | 0.0000000 |
| R | 13.4 | 0.026177 |
| L1 | 16.6 | 0.037838 |
| C1 | 15.294 | 0.034994 |
| C0 | 1.9 | 0.001051 |
| Q | 77.6 | 0.181573 |
| C0/C1 | 121.4 | 0.283101 |

IMPORTANT

This Addendum is intended for customers who purchase computers independently for CNA applications. Transat control and frequency cards use the computer PCI bus. After installation of PCI cards, the computer BIOS will detect and assign base addresses to each PCI card. You, the customer, must then determine the address assigned to each PCI card and enter this address into the Transat operating software.

The installation disk for the Cna-300/Sys now includes a subdirectory called FindPCI. When the application is installed to a user's computer, this directory will be copied to the 'C' drive of the computer.

The \FindPCI directory has two files:

FindPCI.exe => executable that runs in DOS to locate the PCI address of FFC and/or DIO-24 cards.
FindPCI.dat => file used by the FindPCI executable, it lists the cards to look for

To run the program, go to the FindPCI subdirectory and type the executable name.

```
C:\> cd:\FindPCI (changes the path to the proper subdirectory)
C:\> FindPCI (executes the program)
```

The output of the program is a listing of the PCI cards found in the computer, along with their assigned address.

Example output:

| |
|--|
| Fast Frequency Card Address: 0xDC00 |
| DIO24 Address: 0xE040 |

After running the FindPCI program, you must enter the assigned addresses into the CNA System Software.

To do this, you must start the software in Demonstration Mode.

```
C:\> cd:\testmeas (changes the path to the proper subdirectory)
C:\> testmeas -a (executes the demonstration program)
```

To enter the address for the PIO24 card used to talk to the CNA: (refer to section 8.4.2, page 58, of the operating manual.)

From the main operating menu select item:

4. Configure System. Then from the Configuration Menu select:
 4. Internal Parameters. Then from the Internal Parameter Menu select:
 2. Digital I/O Parameters. Enter the CNA address parameter:
CNA PIO-24 Base Address:

CNA Test Measurement Software Operating Manual Addendum 01

To enter the address for the PIO24 card used for External I/O: (refer to section 8.4.3, page 59, of the operating manual.)

From the main operating menu select:

4. Configure System. Then from the Configuration Menu select:
 4. Internal Parameters. Then from the Internal Parameter Menu select:
 3. External I/O Parameters. Enter the I/O address parameter:
I/O PIO-24 Base Address:

To enter the address for the FFC: (refer to section 8.4.4, page 60, of the operating manual.)

From the main operating menu select:

4. Configure System. Then from the Configuration Menu select:
 4. Internal Parameters. Then from the Internal Parameter Menu select:
 7. FFC Card Parameters. Enter the FFC address parameter:
Base Address:

After configuring the PCI card addresses, Press the [Esc] key repeatedly to get back to the main operating menu, then simultaneously press the [ALT] and [F10] keys.

After the demonstration mode shut down, turn the computer off, then restart the computer.